

TM 11-321

WAR DEPARTMENT TECHNICAL MANUAL

ENTO LIBRARY

TEST SET

I-56-E

NOTE. This is a reprint of TM 11-321, Test Set I-56-E, 23 JULY 1943.
No distribution will be made to personnel possessing the original publication

WAR DEPARTMENT

23 JULY 1943

TEST SET

I-56-E



WAR DEPARTMENT

•

23 JULY 1943

WAR DEPARTMENT,
WASHINGTON 25, D. C., 23 July 1943.

TM 11-321, Test I-56-E is published for the information and guidance of all concerned.

[A. G. 062.11 (3 Nov 42).]

BY ORDER OF THE SECRETARY OF WAR:

G. C. MARSHALL,
Chief of Staff.

OFFICIAL:

J. A. ULIO,
*Major General,
The Adjutant General.*

DISTRIBUTION:

TABLE OF CONTENTS

	Paragraph
I Description	
General	1
Component Parts	2
Model 774 Type 4, Analyzer Section.....	3
Volt Ohmmeter Model 564 Type 3C.....	4
Output Meter Model 571 Type 3A.....	5
II Installation and Operation	
General Tests	6
Capacitor Leakage Measurements	
Output Tests	
Selective Analyzer	
Detailed Tests	7
Test for Short Circuit	
Emission Test	
Open Element Test	
Tube Testing	
Testing of Individual Electrodes	
Setting Up Tube Data for New Tubes	
Test of a Typical Radio Set.....	8
III Functioning of Parts	
Model 774 Type 4	9
Model 564 Type 3C.....	10
Model 571 Type 3A.....	11
IV Maintenance	
General	12
Model 774 Type 4	13
Model 564 Type 3C.....	14
Model 571 Type 3A.....	15
V Supplementary Data	
Tube Base Data Connections and Chart.....	16
Test Data for Signal Corps Tubes on Model 774-4.....	17
Commercial Tube Test Data for Model 774-4.....	18
Supplementary Commercial Tube Test Data for Model 774-4.....	19
Cross Index of V.T. and Commercial Tube Type Numbers.....	20
Color Code Charts for Resistors and Capacitors.....	21
List of Replaceable Parts.....	22

LIST OF ILLUSTRATIONS

Fig. No.	Page
1. View of Complete Test Set I-56-E in Carrying Case.....	4
2. View Showing Carrying Case Closed.....	5
3. Model 774 Type 4 Unit Only Showing Panel, Jacks and Controls.....	6
4. View of Adapters Used with the Socket Selector.....	7
5. Diagram of General Jack Arrangement in Socket Selector.....	7
6. Model 564 Type 3C Volt-Ohmmeter.....	8
7. Model 571 Type 3A Output Meter.....	8
8. Diagram Showing How to Extend Resistance Range of Model 564 Type 3C Volt-Ohmmeter	10
9. Diagram of Internal Connections of Model 774 Type 4.....	21
10. Layout of Resistor Strips.....	22
11. Diagram of Internal Connections of Model 564 Type 3C.....	23
12. Diagram of Internal Connections of Model 571 Type 3A.....	24
13. Diagram of Internal Connections of Socket Selector Unit.....	24

DESTRUCTION NOTICE

WHY—To prevent the enemy from using or salvaging this equipment for his benefit.

WHEN—When ordered by your commander, or when you are in immediate danger of capture.

HOW—

1. Smash—Use sledges, axes, hand-axes, pick-axes, hammers, crowbars, etc.
2. Cut—Use axes, hand-axes, machete, etc.
3. Burn—Use gasoline, kerosene, oil, etc.
4. Explosives—Use firearms, etc.
5. Disposal—Bury in slit trenches, fox-holes, other holes. Throw in streams. Scatter.
6. Use ANYTHING IMMEDIATELY AVAILABLE FOR DESTRUCTION OF THIS EQUIPMENT.

WHAT—

1. Smash—Meters and cases.
2. Cut—All internal wires and external cables.
3. Bend—Metal panel of Model 774.
4. Burn—Cases, internal parts, instruction books and test charts.
5. Bury or scatter remainder of all parts after breaking and burning.

DESTROY EVERYTHING

. . . WARNING . . .

The observance or ordinary care in handling this test set will prolong its usefulness.

Don't drop or subject it to heavy jars or shocks. When transporting it in a truck, put it on the seat or on a rubber pad or blanket or other cushioning material to take up shocks.

Don't subject it to moisture . . . Cover it up.

Keep it clean . . . Dirt will impair its operation.

If the glass over the scale becomes cracked or broken . . . replace it to prevent dirt from reaching the movement.




Figure 1
View showing Test Set I-56-E complete with each unit in place in carrying case.

SECTION I

DESCRIPTION

	Paragraph
General	1
Test Set I-56-E	2
Model 774 Type 4, Analyzer Section.....	3
Volt Ohmmeter Model 564 Type 3C.....	4
Output Meter Model 571 Type 3A.....	5

1. GENERAL.—

Test Set I-56-E consists of a set of instruments and auxiliary equipment which is necessary, or desirable, to properly service radio equipment now in use by the various branches of the service.

2. COMPONENTS.—

Test Set I-56-E consists of the following component parts:

1 each Combination Analyzer and Tube Tester Model 774, Type 4 (with 15 adapters, 4 jumper leads, 1 output lead, 1 pair test leads, 1 set of instruction cards.)

1 each Volt-Ohmmeter Model 564, Type 3C

1 each Output Meter Model 571, Type 3A

1 each Technical Manual (for Test Set I-56-E Optional)




Figure 2

Test Set I-56-E complete in carrying case closed.

Test Set I-56-E, as shown in Figure 1, is contained in a steel carrying case made with compartments for each individual component. The position of the various components when placed in the kit ready for transportation is shown in

this photograph. A compartment in the cover of the steel case is supplied for carrying the various instructions. Two locks fitted with identical keys are supplied in the front of the device for locking the complete kit. Figure 2 shows the test set closed and ready for transportation. When the lid is closed the pads in the cover will hold each of the components firmly in position and will also protect them from damage due to external shocks.

Model	Weight	Dimensions
Model I-56-E Test Set	41 lbs.	13 3/4" x 19 3/4" x 6 3/8"
Model 774 Type 4	17 lbs.	11 3/4" x 14" x 5 7/8"
Model 564 Type 3C	1 3/4 lbs.	5 1/2" x 3 3/8" x 2 1/2"
Model 571 Type 3A	1 1/2 lbs.	5 1/2" x 3 3/8" x 2 7/8"

3. MODEL 774 TYPE 4 ANALYZER SECTION.—

Model 774 Type 4 provides facilities for testing receiving type vacuum tubes, as well as functioning as an analyzer for obtaining the voltage, current, capacity and resistance data on various radio sets. All measurements can be made by the direct point-to-point method with the test prods connected to the appropriate terminals in the equipment wiring.

Analysis can also be made at each tube socket using the SOCKET SELECTOR UNIT built into the device. (See Figs. 3, 4, & 5.)

Ranges are as follows:

D. C. Volts	A. C. Volts	D. C. Current
7.5	2.0 (Approx.)	1 Ma.
15	7.5	10 Ma.
50	15	100 Ma.
150	50	500 Ma.
500	150	
1000	500	
	1000	

Resistance	Capacity
0 to 10,000 Ohms	0 to .1 μ f
0 to 100,000 Ohms	0 to 1 μ f
0 to 1,000,000 Ohms	0 to 10 μ f
0 to 10,000,000 Ohms	0 to 100 μ f




Figure 3
Model 774, Type 4 showing panel, jacks, socket selector unit and various controls.

a. A.C. Voltage Ranges. As illustrated in Figure 3, left-hand, or CIRCUIT SELECTOR, switch sets up the various analyzer circuits as well as the necessary tube tester circuits. Rotate this switch clockwise (right) from OFF, to A.C. VOLTS. In this position, measurements are made through an internal copper oxide rectifier unit.

The individual a-c voltage ranges are next se-

lected on the right-hand RANGE SELECTOR. As indicated, ranges of 7.5- 15- 50- 150- 500- and 1000-volt alternating current can be obtained. Where the approximate circuit voltage is not known, this switch should first be set to the 1000-volt position to protect the instrument.

Insert the pair of test leads with the elbow terminals in the pin jacks marked COMMON and VOLTS A.C. - D.C. found above the




Figure 4

View of adapters used with the socket selector for making analysis of receivers and tubes.

RANGE SELECTOR. The RANGE SELECTOR switch can then be turned counter-clockwise (left) to the various lower ranges to obtain the best instrument deflection. For most accurate readings, a range should be selected, if possible, to cause readings to occur in the upper half of the scale.

b. D-C Voltage Ranges. All d-c ranges terminate at the two pin jacks marked COMMON and VOLTS A.C. - D.C. With the CIRCUIT SELECTOR switch at D.C. VOLTS 10,000 Ω /volt, d-c voltage ranges may be selected on the RANGE SELECTOR switch. In this position, a sensitivity of 10,000 Ω /volt is provided to permit more precise readings in high resistance circuits. Since most receiver test data is set up on the basis of measurements at a sensitivity of 1,000 ohms per volt, the ninth position of the CIRCUIT selector marked D.C. VOLTS 1000 Ω /volt is used when reference is made to such test data in the technical manual of any radio set.

c. Resistance Measurements. With the CIRCUIT SELECTOR set to OHMS, various resistance ranges can be obtained. All ranges operate from self-contained batteries. The upper scale of the instrument is calibrated from 1 to 10,000 ohms. The RANGE SELECTOR switch offers ranges which either divide or multiply the basic scale by the factor indicated at the various switch positions, resulting in full scale ranges of 10,000/100,000/1,000,000/10,000,000 ohms. For measuring electrolytic capacitors for leakage with ohmmeter—polarity of test leads are reversed. "COMMON" lead applies to positive potential to condenser being tested.

d. D.C. Current Ranges. With the CIRCUIT SELECTOR set at D.C. MA., d-c ranges of 1,




Figure 5

Sketch showing the internal construction of the socket selector unit. Note that the inner jack of each pair breaks the circuit when a pin is inserted. If contact is made to the outer jack the circuit remains closed.

10, 100 and 500 Ma. are selected with the RANGE SELECTOR switch.

e. Capacity Ranges. Capacity of capacitors in radio equipment may be measured directly on the lower scale of the instrument. Before making capacity measurements, the 115-volt cord and plug should be inserted in a 60-cycle 115-volt source. With the CIRCUIT SELECTOR set at CAP. the RANGE SELECTOR will then provide the various capacity ranges. The capacity scale on the instrument reads from 0 to 10 μ f. full scale. The factors for the various ranges are designated at the respective switch positions, resulting in full scale capacity ranges of .1, 1, 10, and 100 μ f. All paper or electrolytic capacitors can be checked, but at least one side of the capacitor under test must be disconnected

from the receiver circuit to prevent readings from being affected by associated receiver components.

NOTE: The capacity scale of Model 774 is calibrated for use with 60-cycle current only. On 50-cycle current the instrument will read 5/6 of the correct capacity. Multiply all readings taken with 50-cycle supply, by 1.2 to obtain the correct value. No attempt should be made to use this equipment on 25 cycles.

f. Tube Tester. The tube tester section of this model tests for emission, opens and shorts and is used for testing both Signal Corps and commercial types as used in the various radio sets. The device operates from 105-130-volt, 50-60-cycle, a-c line with self-contained potentials set up for reading the emission values of the respective tubes.




Figure 6
Model 564, Type 3C Volt-Ohmmeter.

4. VOLT OHMMETER MODEL 564 TYPE 3C.—

This instrument is a compact volt-ohmmeter for rapid testing of voltage and continuity. Figure

6 shows a view of the panel with the volt ranges available from pin jacks at the top of the panel and ohm ranges at the bottom of the panel. A voltmeter-ohmmeter toggle switch on the left-hand side of the instrument is used for conversion from voltmeter to ohmmeter. The ohmmeter operates directly from a self-contained battery.

5. OUTPUT METER MODEL 571 TYPE 3A.—

This instrument is used mainly when aligning radio sets, output readings being taken on the instrument while making adjustments in conjunction with a signal generator. The meter includes a constant impedance circuit so that the total impedance across the output posts is 4000 ohms on all ranges. The switch can, therefore, be set to any range without upsetting the load on the output tube of the receiver. (See Fig. 7.)

The instrument operates in conjunction with a full wave bridge type copper oxide rectifier for obtaining the a-c readings. A series capacitor, self-contained in the instrument, is supplied for taking output readings directly from the plate circuit of any vacuum tubes. The capacitor isolates the instrument so that d-c potentials will not cause any damage.




Figure 7
Model 571, Type 3A Output Meter.

INSTALLING BATTERIES

I-56-E Test Sets are shipped from the factory without batteries. Batteries must be installed in the Model 564 Type 3C and the Model 774 Type 4. Follow the step by step procedure given below to put the equipment into operation.

Model 564 Type 3C

1. Remove four panel screws and lift instrument out of bakelite case.
2. Remove the screw fastening the black and red rubber covered leads from the battery clamp mounted on back of meter.
3. Connect black lead to negative of 4.5 V battery.
4. Connect red lead to positive of 4.5 V battery.
5. Place battery in clamp on back of meter with battery terminals facing the pin jacks at the bottom of the panel.
6. Put panel in case and replace four corner screws

Model 774 Type 4

1. Remove four panel screws and lift tester out of wooden case.
2. Disconnect the black, green, red and jumper leads from the positive terminal of the rectangular battery clamp.
3. Connect black lead to negative end of 1.5 V battery clamp. (The two hooked projections on the 1.5 V battery clamp are at the negative end.)
4. Connect the green wire and one end of the jumper lead to the positive end of the 1.5 V battery clamp.
5. Remove rectangular wire clamp.
6. Insert a unicell.
7. Replace wire clamp to hold battery in position.
8. Connect free end of the jumper to negative terminal of 4.5 V battery.
9. Connect red lead to positive end of 4.5 V battery.
10. Put tester in case and replace 4 corner screws.

SECTION II

INSTALLATION AND OPERATION

	Paragraph
General Tests	6
Capacitor Leakage Measurements	
Output Tests	
Selective Analyzer	
Voltage and Current Measurements with Socket Selector Unit	
Resistance and Continuity Measurements with Socket Selector Unit	
Detailed Tests	7
Test for Short Circuit	
Emission Test	
Open Element Test	
Tube Testing	
Test of Individual Electrodes	
Setting Up Tube Data for New Tubes	
Test of a Typical Radio Set.....	8

6. GENERAL TESTS.—

a. Capacitor Leakage Measurements. Capacitor leakage measurements can be taken using either Volt-Ohmmeter Model 564 or Analyzer Model 774. In each case, the capacitor resistance readings are limited to the top scale range on the ohmmeter. By using either of the instruments on the highest ohm range and connecting it across a capacitor, a very high or infinite resistance indication should in all cases be obtained when the capacitor is free from leakage.

Capacitor leakage measurements can also be taken using Volt-Ohmmeter Model 564 on the highest ohmmeter range when connecting it across the capacitor. If it is thought that a particular capacitor has a harmful leakage condition but the maximum range of Model 564 still does not permit an indication of the high leakage resistance, a 45-volt B battery should be placed in series with the high range of Model 564. A 315,000-ohm carbon resistor should be used in series with the battery potential so that when the capacitor charges up, the battery potential will not slam the pointer of the test instrument. This arrangement will provide readings up to approximately 10 megohms. The circuit of these external connections to Model 564 is shown in Figure 8.




Figure 8
Diagram showing how to extend resistance range of Model 564, Type 3C, Volt-Ohmmeter.

b. Output Tests. Output meter readings on the receiver can be taken using the a-c voltage ranges directly, or when d-c voltage is also present, as in the plate circuit of a vacuum tube, a blocking capacitor is provided at the pin jack, A.C. VOLTS SERIES COND. of Model 774 (Fig. 3). One of the test leads is inserted in this jack, the other remains in the COMMON jack. When output tests are desired at the voice coil or across other low impedance circuits where the voltage conditions are usually limited, a special low uncalibrated range of approximately 2.0 volts alternating current is provided between the COMMON jack and the jack marked A.C. VOLTS LOW RANGE. Set Circuit Selector to A.C. Volts. Range Selector may be in any position.

When taking a-c readings on Output Meter Model 571 Type 3A never use the series capacitor if actual voltages are to be measured as the impedance of the capacitor will vary with the frequency and, therefore, will materially upset the calibration of the instrument. Where comparisons are made in output, the capacitor may be used provided there are no variations in audio frequency.

CAUTION: Use special care in making measurements on radio sets when power is on. This applies particularly to the plate circuits of transmitters which carry potentials dangerous to life.

c. Selective Analyzer. Free point measurements of voltage, current and resistance can be made directly at the tube sockets under actual operating conditions by using the SOCKET SELECTOR UNIT of Model 774 built into the panel just to the right of the instrument. Suitable adapters for the plug and SOCKET SELECTOR block are provided for all receiver type tubes along with the necessary jumper cables. Tube base charts covering standard commercial tubes including the octal, loctal, miniature, and acorn groups are given in paragraph 16. In Figure 4, note that both the block and the skirted adapter carry the numbering for the various pins in accordance with the numbering shown in these tube base charts. The numbering on the block applies to 7-prong tubes. When other types of tubes are measured, the skirt of the adapter covers the numbering on the block, and provides the correct numbers applying to the particular tube under test.

Note that there are pairs of jacks opposite each pin. The outer jacks are used for voltage measurements and connect through to the various pins. The inner jacks are for current measurements and carry small switches which open the circuit when a jumper cable is inserted in the jack. In this way by using the two jacks opposite any electrode, current to that electrode can be measured on any of the milliamperage ranges of the analyzer. Figure 5 indicates the internal structure of this block and shows how the small open circuiting switch operates for insertion of the milliammeter.

Tube base charts covering standard commercial tubes, including the octal, loctal, miniature, and acorn groups, are shown in paragraph 15. In using these diagrams remember that the numbers on the base diagrams refer to the same numbering on the selector block and skirted adapters. Duplicates of these charts are supplied in the cover of Model 774 Type 4 Carrying Case.

d. Voltage and Current Measurements with Socket Selector Unit. If a test on all tubes does not clear the trouble, voltage and current measurements should be made on the receiver or transmitter using the SOCKET SELECTOR UNIT. Set up the analyzer and select the adapter having the desired number of tube pins to fit the SOCKET SELECTOR UNIT and fit the other adapter on the end of the analyzer plug. Remove the first tube in the transmitter, or receiver, and insert in the block adapter. Place the analyzer plug in the socket vacated by the tube, and connect the grid lead, if any, to the metal cap on the top of the analyzer plug. Connect the tube cap, if any, to the cap lead on the analyzer block. When making connections to the SOCKET SELECTOR UNIT for voltage measurements care should be taken to plug into the outer jack opposite each pin. Plugging into the inner jack will open the circuit resulting in a reading of 0 voltage. (See Paragraph 6C and Fig. 5.) When making connections to the SOCKET SELECTOR UNIT for current measurements, two leads from the milliamperage ranges of the analyzer are plugged into two jacks, one lead into the outer jack, and one lead into the inner jack, opposite the element in the particular circuit to be measured. Plugging into the inner jack opens the circuit to the outer jack and thus places the milliammeter directly in series with the circuit.

If d-c voltage and current measurements are desired, set the CIRCUIT SELECTOR to D.C. VOLTS 1000Ω/Volt or D.C. MA. Reference can then be made under the number of the particular tube being tested, on the tube base charts in Paragraph 16. Two jumper leads are used to connect the tube electrodes to the various instrument ranges.

e. Resistance and Continuity Measurements with Socket Selector Unit. If measurements of this type are desired in place of, or in addition to the volt-milliammeter readings, these can be carried out in very much the same manner by using the SOCKET SELECTOR UNIT in Analyzer Model 774. Instead of connecting the jumper cables to the voltmeter and milliammeter ranges, set up Model 774 for resistance measurements. As most resistance measurements are made with reference to ground, plug the three foot clip lead that is supplied with the equipment into the jack of the analyzer marked COMMON and clip to some grounded portion of the equipment under test. The analyzer pin jack marked VOLTS A.C.-D.C. can then be connected by means of one of the jumper leads to any one of the outer socket selector pin jacks, and the circuit resistance to ground can be measured directly on the instrument.

CAUTION: Before using the ohmmeter, disconnect all potential sources from the transmitter or receiver proper.

7. DETAILED TESTS.—

a. Test for Short Circuit. Refer to tube test data Paragraphs 17, 18, 19. Set FILAMENT SELECTOR as specified. Set CIRCUIT SELECTOR to LINE SHORT CHECK. Insert the tube in the socket carrying the corresponding number of pin holes and allow it to heat up. Rotate LINE VOLTAGE control until meter reads center scale or LINE CHECK. The red electrode switches carrying letters as listed on the instruction card opposite the heading IN POSITION should be thrown one at a time from OUT to IN and back while watching the neon lamp for a short indication. Tap the tube gently with the finger or a pencil while making this test. If any flicker or indication is shown by the neon lamp, reject the tube as unfit for service.

If the tube is of the cathode type, as indicated

by a small star ahead of the tube type number throw the A switch to IN for an indication of cathode leakage. Note that when making short tests each switch is operated independently and is thrown to IN and back while watching the lamp. Do not leave any of the other switches in this position while making the test as each switch is used for testing a particular electrode. When the switch is thrown to IN it isolates that electrode at a definite potential in series with the neon lamp from all other electrodes. For this reason each switch should be manipulated by itself.

b. Emission Test. After the short test has been completed, set the CIRCUIT SELECTOR to NORMAL TUBES and throw the switches opposite the headings IN POSITION simultaneously to IN. This gives a total emission test on the tube. Note that for all normal types, exclusive of battery and diode types, the A switch and REV.-NORMAL switch should be kept at OUT and NORMAL when taking the test readings. If the indication on the instrument is in the red or yellow sections of the scale, the tube has emission below normal.

c. Open Element Test. After making an overall emission test, test the emission of each individual element because an open element may not necessarily result in a low reading on a total emission test. To make an emission test of each individual element, set up the instrument in the usual manner for a total emission test and throw each of the electrode switches used in the test to OUT and IN. As this is done, note a slight, or large, change in instrument deflection. If the manipulation of any one of the switches results in no instrument change, the element connected to that particular switch can be considered open, and the tube rejected as defective. For battery or diode types, indicated by a BAT. or a DI. symbol respectively, the CIRCUIT SELECTOR switch should be turned to BATTERY or DIODE as required while making tests on these tubes. After completing such test be sure you return this switch to NORMAL.

d. Tube Testing. Test data for Model 774 Type 4 for Signal Corps as well as commercial type tubes are given in paragraphs 16, 17, and 18. This information is a duplication of the data given on the tube data cards furnished with Model 774 Tube Checker. A card fastened in the lid of the tube checker is used for quick refer-

ence for some of the more commonly used Signal Corps tubes. For data on tubes other than those listed on the card, refer to paragraphs 16, 17 and 18.

In operating the tube tester section of Model 774 Type 4 plug into an a-c line and turn the CIRCUIT SELECTOR to LINE SHORT CHECK. The instrument reading so obtained is in proportion to the line voltage. Rotating the center control, marked LINE VOLTAGE, the instrument is brought to the black line in the center of the scale labeled LINE CHECK. This operation assures correct test potentials, regardless of the line potential. Before inserting a tube for test, refer to the test data charts in paragraphs 17, 18 and 19, or to the card in the lid of the device. Then set the TUBE SELECTOR and FILAMENT SELECTOR switches to the designated positions.

WARNING: Failure to do this may burn out the tube.

Miniature and battery types can be short checked without harm to the tubes. Filaments can not be damaged due to excess emission because a negative d-c potential is applied to the elements to be short checked. The use of d-c prevents damage to the elements themselves and no artificial indication of shorts will be experienced with Model 774.

When using Tube Tester Model 774, Type 4, keep in mind that any one tube may have several symbols indicating that the procedure outlined for each one of the symbols should be followed. For instance, a tube type having a star and double dagger (*††) should be checked in the A socket corresponding to the pin arrangement of the base, and should be also checked for cathode leakage. The symbols used on the tube chart are listed below and it must be kept in mind that any combination of these symbols might possibly be used following the tube type number.

° When short checking, throw B&D toggles to IN and OUT at the same time.

§ When testing for open elements or short checking, throw F&G toggles to IN and OUT at the same time.

** Reject Point is 16 on 50 Line D.C. Arc.

† Throw switch A to IN before inserting tube; keep in this position during complete

test. A lighted neon lamp will indicate continuity of third filament connection. No short test; refer to instructions.

* Test for cathode leakage by throwing the A switch to IN when tube is hot; all other switches should be at OUT.

†† Test in "A" socket.

¶ Place NORMAL. REV. toggle at REV.; to short check, throw A toggle to IN, leaving G at IN.

|| Place NORM. REV. toggle at REV.

& Move grid lead to the cap that gives the higher reading.

°° Tie both tube caps together.

□ When testing for open elements or short testing, B&H toggles should be thrown to IN and OUT at the same time. The same holds true for C&G toggles. Check for cathode leakage.

If all cable connections seem to be in good condition, test the tubes in the defective receiver or transmitter in Tube Tester Model 774, Type 4 using the following procedure:

- (1) Plug the device into a 60-cycle 110- or 120-volt supply.
- (2) Rotate CIRCUIT SELECTOR to LINE SHORT CHECK.
- (3) Set the FILAMENT SELECTOR in accordance with the tube date.
- (4) If a single dagger (†) appears following the tube type number, move the A toggle to IN before inserting any tubes.
- (5) Insert the tube in the socket corresponding with the proper pin arrangement. If the A socket is to be used, a double dagger (††) will appear after the tube type number on the tube data chart.
- (6) Rotate the LINE VOLTAGE control until the pointer indicates at the LINE CHECK mark.
- (7) Rotate the TUBE SELECTOR to the figure indicated on the tube data chart.
- (8) Now short test the tube in the following manner: Throw the toggle switches at the bottom of the panel to IN and OUT, one at a time. Use only those toggles called for on the data chart under the IN column. If a star (*) follows the tube type number on the data chart, check for cathode leakage by throwing the A

toggle to IN while all other toggles are at OUT. When doing this watch the neon lamp for any indication of shorts.

- (9) Following the tube type number on the tube data chart will appear one of the following abbreviations: Di, Bat., or Spec. Rotate the CIRCUIT SELECTOR to the position indicated by the abbreviation. If no abbreviation appears following the tube type number, the tube can be considered a normal type, and the CIRCUIT SELECTOR should be rotated to NORMAL.

- (10) Throw the toggle switches at the bottom

When satisfied that all the elements are making connection as indicated by the test given above, the tube may be considered as completely satisfactory.

CAUTION: Do not neglect this test of the tubes.

f. Setting Up Tube Data for *New Tubes. Sometimes it is necessary in an emergency to set up tube data for tubes not listed on the data chart. By using the table given below, you can pick proper toggle switches to be thrown to IN. Reference to the base diagram of the tube to be checked will indicate what pin numbers are involved. Determine the type of base, because,

Wiring of Socket Pins to Electrode Switches

Toggle Switches	Octal	Loctal	Miniature	Large & Small 7	Six Prong	Five Prong	Four Prong	Miniature A	Loctal A	Octal A	Acorn
B	3	2	3	2	2	2	2	1	1	3	2
C	4	3	4	3	3	3	3	7	3	4	3
D	5	4	5	4	—	—	—	5	4	5	—
E	Cap	5	Cap	Cap	Cap	Cap	Cap	Cap	Cap	Cap	Cap
F	6	6	6	5	4	—	—	6	6	6	6
G	8	7	7	6	5	4	—	2	7	1	5
H	1	—	—	—	—	—	—	—	5	2	—
First Filament Connection	2	1	7	7	6	5	4	4	2	7	1

of the panel to IN as called for on the tube data chart under the IN column.

- (11) Note meter indication. If pointer is in the red or yellow section, reject the tube as bad. If the pointer indicates in the green section, proceed as outlined below with the separate element check.

e. Test of Individual Electrodes. Individual elements of a tube occasionally develop an open circuit. In an emission test the grid is closest to the cathode and therefore provides the majority of the emission. The plate, screen grids and suppressor grids contribute in smaller proportions to the total emission reading. Thus, if a screen grid or similar element develops an open circuit, the over-all emission reading may only be affected slightly, and the meter may still indicate a good tube. It is desirable, therefore, to test the individual element emission.

To test each element separately, set the tube checker up for normal test as indicated above, and pull each of the toggle switches, one at a time, to OUT and return to IN. A change in meter indications even if only $\frac{1}{4}$ of a division, will indicate that particular element is drawing current.

referring to the table, the letter opposite the pin number is the toggle switch that should be thrown to IN. For example, 6K7 tubes have elements on pins 3, 4, 5, and the cap. As 6K7 has an octal base, a glance at the chart shows that toggle B corresponds to pin 3, C to pin 4, D to pin 5, and E to the grid cap. Cathode connections on heater type tubes can be disregarded as the toggle switch corresponding to that pin must always be set at OUT.

It is also necessary to determine whether the filament connections are normal for the type of base used. If the filament connections are not normal, use the following rule: On the octal based tubes, if one of the filament connections is on pin 2, check the tube in the regular octal socket. If, on an octal based tube, one of the filament connections terminates at 7 and the other end of the filament terminates at any other pin except pin 2, use the octal A socket.

On Locctal tubes, if one filament connection terminates at pin 1, check the tube in the regular locctal socket. If a locctal based tube has one end of its filaments connected to pin 2, and the other end to any other pin except pin 1, use the locctal A socket.

On a miniature based tube, if one end of the filament terminates on pin 7, check the tube in the regular miniature socket. If a miniature based tube has one end of its filament connected to pin 4 and the other end to any other pin except pin 7, check the tube in the miniature A socket.

CAUTION: Watch for tubes with center tapped filaments or tubes with three filament connections. All such tubes require that Switch A be at IN before placing the tube in the tester. All other tubes are checked in sockets corresponding to their pin arrangement and therefore will cause no difficulty.

Filament Potentials. Do not fail to take into account the type of tube that is to be tested. In other words, is it a diode, battery, normal, or special type? Use the DIODE position for diode types and for those battery types in which the load on the tube is too great. It is easy to determine whether the load is too great by placing the tube in the socket and turning the CIRCUIT SELECTOR to BAT. If the meter indication begins to drop off, the load placed upon the tube is too great and the DIODE position should be used instead.

Use the BAT. position for those tubes having more than two elements and having filament voltages corresponding to the 1.5- and 2-volt types. Also use the BAT. for certain 2.8- and 4-volt tapped tubes.

Use the SPEC. Tubes position only on tubes of cold cathode rectifier types, such as the OZ4.

All other types should have the CIRCUIT SELECTOR turned to NORMAL TUBES during test.

The filament potentials provided by the FILAMENT SELECTOR switch are as follows:

Filament Selector Position	Filament Voltage	Filament Selector Position	Filament Voltage
0	1.1 volts	8	13 volts
1	1.5	9	27.5
2	2	10	35
3	2.5	11	47
4	3.3	12	70
5	5	13	85
6	6.3	14	100
7	7.5		

After determining the CIRCUIT SELECTOR and FILAMENT SELECTOR positions and the toggle switches to be used, rotate the TUBE

SELECTOR control around to 50 as a preliminary setting. Then after the tube is inserted and warmed up, rotate the TUBE SELECTOR control back to the left for an approximate reading of 36 on the 50-volt d-c scale.

Data established on this basis is not completely accurate but, in an emergency, will provide a reasonable idea of tube quality until more accurate data can be obtained from the manufacturer.

CAUTION: When setting up emergency data be sure to give proper attention to diodes, battery types and other special tubes. Failure to observe such special types may result in tube damage.

CAUTION: Use great care in measuring potentials over 100 volts especially if the test prod leads are worn or aged.

NOTE: In all cases when shooting trouble with the analyzer or volt-ohmmeter refer to the wiring diagrams. Where part numbers are given under Voltage and Current Measurements they refer to the replaceable parts lists for the Signal Corps equipment.

8. TEST OF A TYPICAL RADIO SET WITH THE I-56-E.—

a. The general method of servicing a radio set is as follows:

(1) Check everything external to the equipment.

(2) In the case of a receiver, localize the trouble by starting with the output tube and working back through the set to the input circuits. In the case of a transmitter, start with the oscillator and power supply and work forward to the output. If the transmitter has an audio amplifier and modulator unit, localize the trouble by starting with the modulator tube and work back to the microphone or input circuit.

(3) In all cases, check one tube stage at a time and be sure it is operating properly before proceeding to the next stage.

Many receivers and transmitters contain high voltages which are dangerous. Always turn off the receiver or transmitter when making any changes or removing plugs or tubes from their sockets. Always read the technical manual or

service notes that accompany any equipment before attempting to repair it.

b. Transmitter or Receiver. Before using any part of Test Set I-56-E read this manual. Study the instrument and become familiar with the switches and controls and their functions.

(1) Before making any electrical checks, inspect the equipment mechanically to make sure that all cables, dynamotors, batteries, antennas, antenna leads, grounds and ground leads, microphones, speakers or earphones, show no visible mechanical or electrical defects. Read the instructions with the equipment to make sure that everything is properly connected.

(2) Using Model 774 or Model 564 of Test Set I-56-E, make a continuity check of all external apparatus and such external continuity checks of the units that are possible. If a chart of resistor values for the equipment is available, check these values with the chart.

Particularly look for any direct short circuits which may damage the apparatus when the power is turned on.

If any short circuits are found, repair them immediately before proceeding any further. Check all fuses used. A sudden surge may have burned out one.

c. Receiver. Using the Model 774 of Test Set I-56-E, check all of the tubes in the receiver for emission and short circuits. Check carefully the proper settings of the rotary and toggle switches for each type of tube with the tube charts located in the lid of Model 774. To avoid replacing tubes in the wrong socket, check one tube at a time and if it is good, put it back in the socket from which it was removed. If it is defective, replace it immediately with a tube that is known to be good.

(1) Turn the receiver on and look for any damaging breakdowns in the receiver or connecting cable. If any appear, turn off the receiver and repair the breakdown before proceeding further. Check everything external that is connected to the receiver.

(2) **Free point check.**—Remove receiver from cabinet and starting with the output tube, remove the tube from its socket, select the proper adapter from the I-56-E and plug

the cable from Model 774 into it and then the cable into the tube socket. Plug the tube into the proper socket on the panel of Model 774. Consult paragraph 3 for the proper settings of the switches and controls.

(3) By means of the current and voltage jacks on the Model 774, check the voltages and current of tube elements. If a voltage chart is available, compare the readings with those on the chart. They should be within 20% if the output stage is operating properly and the B supply voltage is normal. A click should be heard in the headset or speaker when a voltmeter is connected between cathode and control grid of the output tube.

(4) If the output tube is a pentode and the screen voltage is normal, but there is no plate voltage, the trouble probably is in the output transformer. If there is no screen or plate voltage, the trouble is in the power supply unit or cording. Check each part of the power supply such as power transformer, rectifier, vibrator, filter choke, filter capacitors, bleeder resistors and by-pass capacitors.

(5) Using the voltmeter section of the Model 774, check the voltage at the input to the power transformer, at secondaries of the power transformer; check the output of the rectifier, and at each stage of the filtering system, until the B supply to the output tube is reached.

In using Model 774 for this voltage check, be sure that the proper voltage scale is selected, whether the voltage is alternating current or direct current and that it is read on the correct range of the instrument. Also be sure that the normal rated voltage of the power supply is within the maximum voltage rating of the instrument to prevent damage to the meter or any of its multiplier resistors.

(6) With the output stage operating properly, turn off the set, remove the analyzer plug from the output tube socket, and return the tube to its socket in the set. Select the proper adapter, check the preceding audio stage (if there is one) in a similar manner and compare the readings with the voltage chart of the set. If any of the voltage readings are abnormal, trace each circuit element of the audio stage, checking all of the resistors

and capacitors immediately connected with it.

(7) Return the audio tube to its socket and connect the analyzer plug to the detector socket. If the detector is triode or pentode, voltage checks may be made in the same manner as the audio stage. If the detector is a diode, no voltage measurements can be made, except the filament voltage.

(8) A rough check of the detector may be made by switching the meter of Model 774 for resistance and touching the two test leads to the plate and cathode of the diode. Be sure that any controls in the audio circuit are turned to maximum volume. A loud click should be heard in phones or speaker if the audio portion of the detector circuit is operating.

(9) Return the detector tube to its socket. Selecting the proper adapter, check the voltages of each intermediate frequency stage, starting with the last one. When using the Model 774 for voltage and current checks on intermediate frequency stages, r-f oscillator mixer stage and r-f amplifier stage, only static voltages and current can be measured because the capacity of the analyzer cable will detune the circuit to which it is connected.

(10) In the case of the oscillator, the cable capacity may stop the oscillator from operating. In these cases, the static conditions may be different from the dynamic or operating conditions. After the i-f stages have been checked, a static check of the oscillator and r-f stages should be made in a similar manner.

(11) If the above checks have not located the source of trouble, first check the oscillator for operation by measuring the grid current. Unsolder the ground or low potential wire of the oscillator grid return.

(12) To use Model 774 as a milliammeter, connect it between the wire, just unsoldered, and ground. The positive side of the meter connects to ground. Turn the set on and read the grid current on the meter, selecting the scale that gives the highest reading on the meter scale.

(13) On most receivers, this current is never over one milliamper. The product of the grid current times grid resistance is the r-f voltage produced by the oscillator. If there is no grid current, or only a very slight

indication on the meter, the tube is not oscillating. Check all of the component parts of the oscillator coil for open circuit or shorted turns, and replace the defective element.

(14) With the oscillator operating properly, check the parts of each circuit of the receiver, such as the automatic volume control circuit. All resistors and capacitors connected with it should be checked for open and short circuits and also for their correct values. Starting with the last i-f stage, such continuity checks as are possible, should be made on the i-f and r-f stages to determine whether the coils, accompanying by-pass capacitors, or r-f filter resistors are shorted, open, or have changed value.

(15) If a signal generator is available, an alignment check should be made in accordance with instructions for that particular receiver, using Output Meter Model 571 of I-56-E as an output indicator.

(16) Volt-ohm Tester Model 564, has a higher d-c voltage range than Model 774 and, being smaller and easier to handle, may be more convenient for making d-c voltage measurements and continuity or resistance measurements within its range than Model 774.

d. Transmitter.—Check all external parts directly connected with the transmitter, such as cables, connecting plugs, etc. If the power source is not from the transmitter, check it for proper power output.

(1) Using Model 774 unit of I-56-E, test such tubes as possible in the emission checker for emission and short circuits. Most transmitters have either meters built into the unit, or jacks available in which to plug meters in order to check performance. If the oscillator tube is not operating, the readings at all of the metering jacks may not correspond to the chart for the transmitter.

(2) After all the external parts of the transmitter have been checked and repaired, remove the transmitter from its rack or case, following the instruction for the particular unit. Start with the oscillator unit, using either Model 774 or Model 564 unit of I-56-E for continuity and voltage measurements. BE SURE THAT THE VOLTAGES TO BE

MEASURED ARE WITHIN THE RANGE OF THE METER USED OR THE INSTRUMENT MAY BE DAMAGED BY EXCESSIVE VOLTAGES. If the oscillator is crystal controlled, either check the crystal in another unit or replace it with one known to be good. Check all of the parts associated with the oscillator unit, replacing those that are defective.

(3) Using the same instruments, check each successive doubler, tripler or amplifier stage. If the tubes cannot be checked, replace them with tubes of the same type known to be good. After the r-f section has been fully checked and defective parts replaced, align the transmitter following the instructions for that unit.

(4) To test the modulator section of the transmitter, start with the audio output or modulator tube. If the voltage range of Model 774 unit of I-56-E permits, and the adapters are available for the tubes used, use the SOCKET SELECTOR and check voltage and current of the modulator tube. If there are no voltages, or the voltages are low, check all of the parts associated with the modulator stage and the connection to the power supply. Repair or replace the defective parts, using Model 774 or Model 564 as a check means.

(5) Make the same check of each successive stage of the modulator amplifier. Check all values of current or voltage at the available meter jacks or the built-in meters.

SECTION III

FUNCTIONING OF PARTS

	Paragraph
Model 774 Type 4	9
Model 564 Type 3C	10
Model 571 Type 3A	11

9. MODEL 774 TYPE 4.—

a. The large instrument in the light wood case is Model 774, Type 4, a combination tube checker, volt-ohmmeter, capacity meter, and analyzer. The instrument has a basic sensitivity of 100 microamperes and an internal resistance of 1,238 ohms. It is connected for the various types of measurements, such as tube testing, d-c volt measurements, ohms, etc., by means of the left-hand, or CIRCUIT SELECTOR, switch. The right-hand, or RANGE SELECTOR, switch is not used for tube testing, but is required to select the particular volt, ohm, milliampere, or capacity range required.

b. The tube tester section includes an emission tube checker with separate loads for diodes, battery types and cathode or so called normal types. Selection by type using the CIRCUIT SELECTOR connects 5000 Ω , 1000 Ω , and 200 Ω respectively into the electrode circuits. Each red handled toggle switch connects to a socket pin so that continuity and short tests can be made by using each switch individually. A d-c potential of approximately 120 volts is developed by the transformer and the type 71A rectifier tube, operating as a diode. As each switch is thrown to IN, the corresponding element is separated from all other electrodes, and connected with the d-c potential and neon lamp in series to the return circuit. Should there be a short or resistance equal to $\frac{1}{4}$ meg. or less, to any other electrode including cathode, filament, and shell, the lamp will glow. This $\frac{1}{4}$ meg. value is obtained by shunting the neon lamp with a resistance network.

c. A normal-reverse switch is required for a few new types where the plate of the rectifier section is connected to a tap on the tube filament such as in the 70A7-GT. This effectively reverses the meter so that it will indicate the cathode condition by an up-scale deflection.

d. The d-c meter operates as a milliammeter in series with a measured potential, an accurate

low resistance and the tube electrodes. A ring shunt circuit with a calibrated control (TUBE SELECTOR) provides the means for adjusting the sensitivity for each tube. The tube under test acts as its own rectifier converting the alternating current from the transformer into direct current, as indicated by a steady meter deflection.

e. As a capacity meter, the meter is connected to a full wave bridge type rectifier, in series with an a-c potential and adjusted current-limiting resistance. The a-c potential is adjusted by means of the LINE VOLTAGE potentiometer until the required full scale current flows through the meter, with the test leads shorted. The leads are then connected across the condenser under test, and the reduction in current flow due to the series reactance of the condenser is measured. This is calibrated in terms of microfarads on the meter scale.

f. As an ohmmeter, the instrument operates as a d-c microammeter in series with measured fixed resistance and either a 1.5- or 6-volt battery. The ratio of unknown to known resistance is indicated on the meter in terms of resistance calibration on the scale. The current sensitivity of the meter is adjusted by means of the OHM-METER ADJUSTER to take care of battery potential variation. This is the 15,000-ohm, or high resistance, section of the dual potentiometer.

g. As a d-c voltmeter, the meter is used directly with its 100 microampere sensitivity in series with measured 10,000-ohm per volt resistors for the various ranges. This requires a total resistance of 10 megohms for the highest range. For 1000 ohms per volt, the 1MA. position of the ring shunt is used for meter sensitivity, with 1000 ohms per volt adjusted resistors for each voltmeter range.

h. As an a-c voltmeter, the meter is used with a rectifier network and separate shunt, for 1

milliampere a-c. The 1000 ohms per volt resistors used for the d-c ranges are also used for the a-c ranges.

10. VOLT-OHMMETER MODEL 564, TYPE 3C.—


This is a compact volt-ohmmeter, having a basic sensitivity of 100 microamperes. A toggle switch is provided for connecting the instrument as either an ohmmeter or a voltmeter. When the toggle switch is at VM, the instrument is shunted to a basic sensitivity of 1 milliampere, and the necessary series resistors connected to the respective voltmeter pin jacks provide the indicated ranges of 3-, 30-, 300-, 600-, and 1800-volt direct current.

With the toggle switch at RES., the full sensitivity of the instrument is utilized and appropriate resistor networks are connected to the various resistance pin jacks in series with a 4.5-volt battery to provide resistance ranges of 1,000, 10,000, 100,000, and 1 megohm maximum. In the ohmmeter circuit will be found a 10,000-ohm variable rheostat and a 2,000-ohm fixed resistor. (See Fig. 11.) This resistance circuit constitutes a variable shunt directly across the instrument terminals, thereby providing for the

necessary compensation needed to adjust the ohmmeter circuit for various conditions of battery potential.

11. OUTPUT METER MODEL 571 TYPE 3A.—

This instrument is designed around a d-c instrument having a basic sensitivity of approximately 250 microamperes direct current, and is adjusted at the factory in conjunction with a copper oxide rectifier to provide a final sensitivity of 375 microamperes alternating current. Connected between the instrument rectifier and the selector switch is an appropriate resistor network to provide a constant impedance of 4,000 ohms on ranges of 1.5-, 6-, 15-, 60-, and 150-volt alternating current. (See Fig. 12.) A constant impedance is necessary in order to maintain a constant load when taking measurements in the output circuit of a radio receiver. All ranges terminate in appropriate pin jacks at the top of the panel. The extreme left-hand pin jack connects to a 0.2 μ f series capacitor. This capacitor is used to isolate any direct current which may be present in the circuit where a-c signal voltages are to be measured.



NOTES

Corresponding circled figures connect together.

"Range Selector" (4 deck sw) shown in 7.5V position.

"Circuit Selector" (6 deck sw) shown in "Spec. Tubes" position.

Abb. "M" 1,000; example, 143 M=143,000.

Abb. "Meg." 1,000,000; example, 5 Meg.=5,000,000.

Figure 9
Diagram of internal connections of Model 774 Type 4.

SECTION IV MAINTENANCE

	Paragraph
General	12
Model 774 Type 4	13
Model 564 Type 3C	14
Model 571 Type 3A	15

12. GENERAL.—

Several of the component parts of Test Set I-56-E are equipped with self-contained batteries or with fuses for the protection of the device. The following instructions are for replacing these batteries and fuses:

13. MODEL 774 TYPE 4.—

a. On the ohmmeter ranges of this unit, the current is supplied from two self-contained batteries fastened inside the wooden case. If these batteries fall off in potential due to use or shelf depreciation, the BATTERY ADJUSTMENT

will have to be turned higher each time the instrument is used. When complete rotation of BATTERY ADJUSTMENT will not bring the pointer to top scale, replace the battery. To do this, remove the four corner panel screws and lift the complete tester out of its case. This will provide access to the 4½-volt battery and the 1½-volt battery in the wood case. To remove the 1½-volt unicell, place the thumb over the positive battery end of the clamp pressing toward the battery, and pull up the wire clamp. The clamp can be removed entirely, and the battery lifted out of the clips. Put in the new battery, and place the open end of the wire clamp




Figure 10
Layout of resistor strips.

over the two projections at the negative battery end, and snap the clamp down over the thumb spring at the positive end. The operator should carefully check the connections to the new batteries. After fastening the batteries into position, the tester may be placed in the case and the four corner panel screws tightened. If replacement of one or both of the batteries does not correct the trouble, or if the tester does not function properly on the volt or milliamperage ranges, it should be turned in as defective. Do not attempt to fix the instrument, as considerable damage may be done if the operator is not entirely familiar with this type of equipment.

b. Tube Tester Model 774 contains a transformer operating on the a-c line for supplying the electrode potentials to the tubes. Two one-ampere fuses are contained in the plug at the end of the 115-volt cord, to protect the tester from overload. Should the device fail to function when plugged into a line known to be alive, the one-ampere fuses should be removed and replaced. This is done by merely pushing the fuses out of the plug with a pencil or some other suitable implement.

c. If the tester still does not function or if no LINE CHECK reading is obtained with the tester turned on, examine 71-A RECTIFIER TUBE mounted inside the device. If it is burned out, replace with a new one of the same type. **CAUTION:** No attempt should be made to correct defects other than those mentioned, as doing so may cause serious damage to the device.

14. MODEL 564 TYPE 3C.—

This device contains one $4\frac{1}{2}$ -volt battery to supply current for the ohmmeter ranges. If the potential of this battery falls off due to use or shelf depreciation, rotate the BATTERY ADJUSTMENT further each time. This is especially apparent on the low ranges where considerable current is drawn. When complete rotation of BATTERY ADJUSTMENT will not bring the pointer to the top scale division

replace the battery. To do this, remove the four panel mounting screws and lift the tester out of its case. The battery will be readily accessible on the back of the instrument. Note the color coding of the battery leads, the red lead connecting to the positive terminal.

CAUTION: Should the above recommendations fail to correct the trouble or should the instrument not function properly in any other respect do not attempt to fix the device as considerable damage may be done if the operator is not entirely familiar with the repairing of this type of equipment.

15. MODEL 571 TYPE 3A.—

No attempt should be made to service this device, as doing so may cause serious damage.




Figure 11

Diagram of Model 564 Type 3C Volt-Ohmmeter. Looking at back of panel.



Figure 12

Diagram of Model 571 Output Voltmeter. Looking at back of panel.




Figure 13


Diagram of internal connections of Model 666 Type 1C Socket Selector. Looking at back of panel.

SECTION V


SUPPLEMENTARY DATA

	Paragraph
Tube Base Data Connections and Chart.....	16
Test Data for Signal Corps Tubes on Model 774 Type 4.....	17
Commercial Tube Test Data for Model 774 Type 4.....	18
Supplementary Commercial Tube Test Data for Model 774 Type 4	19
Cross Index of VT and Commercial Tube Type Numbers.....	20
Color Code Charts for Resistors and Capacitors.....	21
List of Replaceable Parts.....	22


16. TUBE BASE DATA CONNECTIONS AND CHART



16. TUBE BASE DATA CONNECTIONS AND CHART (Continued)



16. TUBE BASE DATA CONNECTIONS AND CHART (Continued)



16. TUBE BASE DATA CONNECTIONS AND CHART (Continued)



16. TUBE BASE DATA CONNECTIONS AND CHART (Continued)

Tube Type	Base	Tube Type	Base	Tube Type	Base	Tube Type	Base	Tube Type	Base
00	4D	1N6-G	7AM	6AC6-G	7W	6N7	8B	7N7	8AC
00A	4D	1P1	4T	6AC7/1852	8N	6P5-G	6Q	7Q7	8AL
0A4	4V	1P5-G	5Y	6AD5-G	6Q	6P7-G	7U	7R7	8AE
0Z3	5N	1Q1	4T	6AD6-G	7AG	6Q6-G	6Y	7S7	8BL
0Z4	4R	1Q5-GT	6AF	6AD7-G	8AY	6Q7	7V	7T7	X-29
01	4D	1R1-G	4T	6AE5-GT	6Q	6R6-G	6AW	7V7	8V
01A	4D	1R5	7AT	6AE6-G	7AH	6R7	7V	7W7	8BJ
01AA	4D	1S1-G	4T	6AE7-GT	7AX	6S6-GT	5AK	7Y4	5AB
01B	4D	1S4	7AV	6AF5-G	6Q	6S7-G	7R	7Z4	5AB
1	4G	1S5	6AU	6AF6-G	7AG	6SA7	8R	8	4A
1A1	4A	1T1-G	4T	6AF7	8AG	6SA7-GT	8AD	9	4A
1A3	5AP	1T4	6AR	6AG5	X-36	6SC7	8S	10	4D
1A4-P	4M	1T5-GT	6X	6AG7	8Y	6SD7-GT	8N	12A	4D
1A4-T	4K	1-V	4G	6AH5-G	6AP	6SE7-GT	8N	12A5	7F
1A5-G	6X	1V1	4A	6AH7-GT	8BE	6SF5	6AB	12A6	7AC
1A6-GT	6L	1Y1	4A	6AL6-G	6AM	6SF7	7AZ	12A7	7K
1A6S	6L	1Z1	4A	6A7	7C	6SG7	8BC	12A8-GT	8A
1A7-G	7Z	2	4A	6A7-M	8A	6SH7	8BK	12AH7-GT	8BE
1B1	4A	2A3	4D	6A7-S	7C	6SJ7	8N	12B7	8V
1B4	4K	2A3-H	4Q	6A8	8A	6SK7	8N	12B8-GT	8T
1B4-P	4M	2A4-G	5S	6B4-G	5S	6SL7-GT	8BD	12C8	8E
1B5/25S	6M	2A5	6B	6B5	6AS	6SN7-GT	8BD	12E5-GT	6Q
1B7-G	7Z	2A6	6G	6B6-G	7V	6SQ7	8Q	12F5-GT	5M
1C1	4A	2A7	7C	6B7	7D	6SR7	8Q	12G7	7V
1C5-G	6X	2B6	7J	6B8	8E	6SS7	8N	12H6	7Q
1C6	6L	2B7	7D	6C4	6BG	6ST7	8Q	12J5-GT	6Q
1C7-G	7Z	2E5	6R	6C5	6Q	6T5	6R	12J7-GT	7R
1D1	4A	2G5	6R	6C5-G	6Q	6T7-G	7V	12K7-GT	7R
1D5-GP	5Y	2S/4S	5D	6C6	6F	6U5/6G5	6R	12K8	8K
1D5-GT	5R	2V3-G	4Y	6C7	7G	6U6-GT	7AC	12Q7-GT	7V
1D7-G	7Z	2W3	4X	6C8-G	8G	6U7-G	7R	12SA7	8R
1D8-GT	8AJ	2X2/879	4AB	6D5	6Q	6V6	7AC	12SA7-GT	8AD
1E1	4A	2Y2	4AB	6D6	6F	6V7-G	7V	12SC7	8S
1E4-G	5S	2Y3	4C	6D7	7H	6W5-G	6S	12SF5	6AB
1E5-G	5R	2Y4	5D	6D8-G	8A	6W6-GT	7AC	12SF7	7AZ
1E5-GP	5Y	2Z2	4B	6E5	6R	6W7-G	7R	12SG7	8BC
1E7-G	8C	3	4A	6E6	7B	6X5	6S	12SH7	8BK
1F1	4A	3A4	7BB	6E7	7H	6Y3	4AC	12SJ7	8N
1F4	5K	3A5	7BC	6F5	5M	6Y5	6J	12SK7	8N
1F5-G	6X	3A8-GT	8AS	6F5-G	5M	6Y6-G	7AC	12SL7-GT	8BD
1F6	6W	3C5-GT	7AQ	6F6	7S	6Y7-G	8B	12SN7-GT	8BD
1F7-G	7AD	3LE4	X-14	6F7	7E	6Z3	4G	12SQ7	8Q
1F7-GH	7AD	3LF4	6BB	6F7-S	7E	6Z4	5D	12SR7	8Q
1F7-GV	7AD	3Q4	7BA	6F8-G	8G	6Z5	6K	12Z3	4Q
1G1	4A	3Q5-GT	7AP	6G5	6R	6Z6	7Q	12Z5	6K
1G4-G	5S	3S4	7BA	6G6-G	7S	6Z7-G	8B	14	5E
1G5-G	6X	4	4A	6G7	7N	6ZY5-G	6S	14A4	5AC
1G6-G	7AB	4A6-G	8L	6G7S	7N	7	4A	14A5	6AA
1H4-G	5S	4S	5D	6H4-GT	5AF	7A4	5AC	14A7	8V
1H5-G	5Z	5	4A	6H5	6R	7A5	6AA	14B6	8W
1H6-G	7AA	5T4	5T	6H6	7Q	7A6	7AJ	14B8	8X
1J1	4A	5U4-G	5T	6H7	7P	7A7-LM	8V	14C5	6AA
1J5-G	6X	5V4-G	5L	6H7-S	7P	7A8	8U	14C7	8V
1J6-G	7AB	5W4	5T	6H8	8E	7B4	5AC	14E6	8W
1K1	4A	5X3	4C	6J5	6Q	7B5	6AE	14F7	8AC
1L1	4T	5X4-G	5Q	6J6	7BF	7B6	8W	14H7	8V
1L4	X-39	5Y3-G	5T	6J7	7R	7B7	8V	14J7	8AR
1LA4	5AD	5Y4-G	5Q	6J7-G	7R	7B8	8X	14N7	8AC
1LA6	7AK	5Z3	4C	6J7-GT	7R	7C5	6AA	14Q7	8AL
1LB4	5AD	5Z4	5L	6J8-G	8H	7C6	8W	14R7	8AE
1LB6	8AX	6	4A	6K5-G	5U	7C7	8V	14S7	8BL
1LC5	7AO	6A3	4D	6K6-G	7S	7E6	8W	14W7	8BJ
1LC6	7AK	6A4/LA	5B	6K7	7R	7E7	8AE	14Y4	5AB
1LD5	6AX	6A5-G	6T	6K8	8K	7F7	8AC	14Z3	4G
1LE3	4AA	6A6	7B	6L5-G	6Q	7G7	8V	15	5F
1LH4	5AG	6AB5	6R	6L6	7AC	7H7	8V	17	5A
1LN5	7AO	6AB6	7AU	6L7	7T	7J7	8AR	18	6B
1N1	4T	6AB7/1853	8N	6N5	6R	7K7	8BF	19	6C
1N5-G	5Y	6AC5-G	6Q	6N6-G	7AU	7L7	8V	20	4D

16. TUBE BASE DATA CONNECTIONS AND CHART (Continued)

Tube Type	Base	Tube Type	Base	Tube Type	Base	Tube Type	Base	Tube Type	Base
22	4K	49	5-C	90	6N	958	X-8	D-1½	4B
24A	5E	49A2	X-4	91	6N	959	X-7	D-1	4C
24S	5E	49B2	X-4	92	6N	985	5D	DE	4D
25	6M	50	4D	95	6B	986	4C	E	4D
25A6	7S	50A5	6AA	96	4G	1201	X-26	G	4D
25A7-G	8F	50C6-G	7AC	98	5D	1203	X-27	GA	5B
25AC5-GT	6Q	50L6-GT	7AC	112A	4D	1204	X-28	G-2	5D
25B5	6D	50Y6-GT	7Q	117L7-GT	8AO	1221	6F	G-2S	5D
25B6-G	7S	50Z6-G	7Q	117M7-GT	8AO	1223	7R	G-4	5D
25B8-GT	8T	50Z7-G	8AN	117N7-GT	8AV	1231	8V	G-4S	5D
25C6-G	7AC	51	5E	117P7-GT	8AV	1232	8V	G-84	5D
25D8-GT	8AF	52	5C	117Z6-GT	7Q	1284	X-29	H	4D
25L6	7AC	53	7B	165R	4A	1291	X-30	HY-114B	X-33
25N6-G	7W	55	6Q	165R4	X-3	1293	X-31	HY-615B	X-34
25S	6M	56	5A	165R8	X-3	1294	X-27	K-24	5E
25X6-GT	7Q	56AS	5A	181	4D	1299	6DB	K-27	5A
25Y4-GT	5AA	56S	5A	182A	4D	1602	4D	KR-1	4G
25Y5	6E	57	6F	182B	4D	1603	6F	KR-2	4G
25Z3	4G	57AS	6F	183/483	4D	1609	5K	KR-5	5B
25Z4	5AA	57S	6F	185R	4A	1612	7T	KR-20	6N
25Z5	6E	58	6F	185R4	X-3	1613	7S	KR-22	6N
25Z6	7Q	58AS	6F	185R8	X-3	1614	7AC	KR-25	6B
26	4D	58S	6F	210T	4D	1620	7R	KR-28	5D
27	5A	59	7A	213	4C	1621	7S	KR-31	4G
27HM	5A	59A	7A	213B	4C	1622	7AC	KR-98	5D
27S	5A	59S	7A	216	4B	1625	X-16	KR-7184	X-38
29	6N	64	5E	216B	4B	1626	6Q	LA	5B
30	4D	65	5E	257	5B	1629	X-13	P-861	5D
31	4D	67	5A	264	4D	1631	7AC	PZ	5B
32	4K	68	5E	291	5G	1632	7AC	PZH	5B
32L7-GT	8Z	69	5E	293	5G	1633	8BD	RA-1	4Q
33	5K	70	6N	295	5G	1634	8S	RE-1	4C
34	4M	70A7-GT	8AB	482A	4D	1635	X-22	RE-2	4B
35	5E	70L7-GT	8AA	482B	4D	1642	X-17	RK-19	X-1
35A5-LT	6AA	71A	4D	483	4D	1851	7R	RK-21	4AB
35L6-GT	7AC	75	6G	484	5A	1852	8N	RK-22	X-1
35Y4	5AL	75M	7V	485	5A	1853	8N	RK-24	4D
35Z3-LT	4Z	75S	6G	486	X-9	9001	X-18	RK-33	X-17
35Z4-GT	5AA	76	5A	585	4D	9002	X-19	RK-34	X-37
35Z5-GT	6AD	77	6F	586	4D	9003	X-18	RK-47	5J
35Z6-G	7Q	77M	7R	801	4D	9004	X-23	RK-62	4D
36	5E	78	6F	803	5J	9005	X-24	SO-1	4Q
37	5A	78S	6F	804	5J	A (5)	5H	SO-2	4D
38	5F	79	6H	807	X-11	A (6)	6N	V-99	4E
39/44	5F	80	4C	837	X-15	A-22	4D	VR-50	4W
40	4D	81	4B	840	5J	A-26	4D	VR-75-30	X-12
40Z5	6AD	82	4C	841	4D	A-28	4D	VR-90-30	4W
41	6B	82V	4L	842	4D	A-30	4Q	VR-105-30	X-12
41M	7S	83	4C	843	5A	A-32	4Q	VR-150-30	X-12
42	6B	83V	4L	864	4D	A-40	4Q	WE-215A	4D
42A2	X-4	84/6Z4	5D	865	X-2	A-48	4Q	WE-231D	4D
42B2	X-4	85	6G	874	4S	AC-22	5E	WE-257A	X-20
43	6B	85AS	6G	878	4P	AD	4G	WE-300A	4D
43-MG	7S	85L7	8AB	879	4AB	AF	4C	WE-300B	4D
44	5F	85M	7V	884	6Q	AG	4C	WE-306A	X-21
45	4D	85S	6G	885	5A	AX	4Q	WE-307A	5J
45Z3	5AM	86M	6Q	950	5K	B	4E	WE-350A	X-11
45Z5-GT	6AD	87S	6F	951	4K	BA	4J	WE-713A	8BK
46	5C	88	4C	954	X-5	BH	4J	WE-717A	X-35
46A1	X-10	88S	6F	955	X-6	BR	4H	X-99	4D
46B1	X-10	89	6F	956	X-5	BX	4D	XXD	8AC
47	5B	89RS	7N	957	X-8	CK-1005	X-32	XXL	5AC
48	6A								

17. TEST DATA FOR SIGNAL CORPS TUBES ON MODEL 774-4

Tube Type	Fil. Sel.	Tube Sel.	IN Pos.	Tube Type	Fil. Sel.	Tube Sel.	IN Pos.	Tube Type	Fil. Sel.	Tube Sel.	IN Pos.
VT-25	7	38	BC	VT-105*††	6	40	BH&CD	VT-198-A*	6	42	BCD
VT-25-A	7	38	BC	VT-107*	6	42	BCD	VT-199*	6	42	BCFG
VT-27 Bat.	2	19	BC	VT-107-A*	6	42	BCD	VT-201*	9	45	BCD
VT-28*	3	40	BCE	VT-107-B*	6	42	BCD	VT-201-C*	9	45	BCD
VT-29	3	39	BC	VT-112*	6	45	BCFG	VT-202*°††	6	43	BDF
VT-30	5	36	BC	VT-114	5	42	C&F	VT-203*††	6	42	BDF
VT-31 Bat.	2	19	BC	VT-115*	6	43	BCD	VT-205*††	6	41	FH
VT-33 Bat.	2	24	BCG	VT-115-A*	6	43	BCD	VT-205 Di.††	6	0	C&D
VT-35*	3	40	BCE	VT-116*	6	42	BCFG	VT-206-A	5	44	C&F
VT-36*	6	40	BCE	VT-116-B*	6	42	BCFG	VT-207*††	8	41	BG&DF
VT-37*	6	39	BC	VT-117*	6	42	BCFG	VT-208*	6	42	BCDEF
VT-38*	6	39	BCE	VT-120*	6	42	BCEF	VT-209*	8	45	CFG
VT-44 Bat.	2	20	BCE	VT-121*	6	43	BC	VT-210 Bat.§	1	26	BCFG
VT-45	3	41	BC	VT-124 Bat.	1	21	BCD	VT-211*	6	45	CFG
VT-47	3	41	BCG	VT-125 Bat.	1	26	BCD	VT-212 Di.**	0	12	BC
VT-48*	6	42	BCF	VT-126*	6	43	B&D	VT-213-A*	6	41	BD
VT-49*	6	41	BCE	VT-126-A*	6	43	B&D	VT-214 Di.*	8	0	B&D
VT-50	7	37	BC	VT-126-B*	6	43	B&D	VT-215*	6	36	BCF
VT-51	7	38	BC	VT-131*	8	42	BCFG	VT-221 Bat.†	3	28	ABCD
VT-52	7	40	BC	VT-132*	8	44	BCDEF	VT-223 Bat.	1	16	BE
VT-54 Bat.	2	20	BCE	VT-133*††	8	41	FH	VT-224*&	6	42	CE&EF
VT-55	7	20	BCE	VT-133 Di.††	8	0	C&D	VT-225	5	39	BCEG
VT-56*	3	41	BC	VT-134*	8	42	BCD	VT-227	6	41	BCD
VT-57*	3	42	BCEF	VT-135*	8	42	BD	VT-229*††	6	41	CD&GH
VT-58*	3	42	BCEF	VT-135-A*	8	42	BD	VT-231*††	6	43	CD&GH
VT-63	3	41	BCG	VT-137*	8	41	BD	VT-233*††	6	41	FH
VT-65*	6	41	BD	VT-138*	8	37	BCD	VT-233 Di.††	6	0	C&D
VT-66*	6	42	BCD	VT-145	5	39	B&C	VT-234° Bat.	0	19	E
VT-67 Bat.	2	19	BC	VT-146 Bat.	1	22	BCE	VT-235*°°	6	41	E
VT-68*	6	37	BCE	VT-147 Bat.	1	23	BCDEF	VT-237 Di.**	0	3	BC
VT-68 Di.	6	0	D&F	VT-148 Bat.	1	22	BCD	VT-238*	6	43	BCEF
VT-69*	6	41	BCEF	VT-148 Bat.	1	15	EF	VT-239 Bat.	1	24	BF
VT-70*	6	24	DF	VT-148 Di.	1	0	G	VT-243 Di.*	6.3	0	D
VT-70*	6	38	BCE	VT-149 Bat.	3	24	ABCE	VT-264 Bat.†	3	28	ABCFG
VT-72	7	40	BC	VT-149 Bat.†	3	20	ADF	VT-268*††	8	41	BH&CD
VT-73*	3	40	BC	VT-149 Di.†	3	0	AG				
VT-74	5	44	C&F	VT-150*	6	44	BCDGH				
VT-75*	6	41	BE	VT-151*	6	43	BCDEF				
VT-75 Di.	6	0	C&F	VT-151-B*	6	43	BCDEF				
VT-76*	6	39	BC	VT-152*	6	42	BCD				
VT-77*	6	41	BCEF	VT-153*	8	38	BEF				
VT-78*	6	41	BCEF	VT-153 Di.	8	0	C&D				
VT-80	5	36	B&C	VT-161*	8	44	BCDGH				
VT-83	5	43	B&C	VT-162*	8	42	BCFG				
VT-84*	6	42	B&C	VT-163*	6	41	BE&DF				
VT-86*	6	40	BCDE	VT-164	3	42	BCDG				
VT-86-A*	6	40	BCDE	VT-165	3	42	BCE				
VT-86-B*	6	40	BCDE	VT-167	6	44	BCDEF				
VT-87*	6	43	BCDE	VT-168-A*	6	45	BCD				
VT-87-A*	6	43	BCDE	VT-169	8	38	BEF				
VT-88*	6	41	BE	VT-170 Bat.	2	20	BCE				
VT-88 Di.	6	0	C&D	VT-171 Bat.	1	25	BCFG				
VT-88-A*	6	41	BE	VT-172 Bat.	1	18	CDF				
VT-88-A Di.	6	0	C&D	VT-172 Di.	1	0	B				
VT-89*	6	40	BCEF	VT-173 Bat.	1	25	BFG				
VT-90*	6	39	B&D	VT-174 Bat.†	3	28	ABCFG				
VT-91*	6	41	BCDE	VT-175*	6	40	BCD				
VT-91-A*	6	41	BCDE	VT-176*	6	44	BCFG				
VT-92*	6	42	BE	VT-177 Bat.	1	18	BF				
VT-92 Di.	6	0	C&D	VT-177 Di.	1	0	D				
VT-92-A*	6	42	BE	VT-178 Bat.	1	17	BCDEF				
VT-92-A Di.	6	0	C&D	VT-179 Bat.	1	24	BCDF				
VT-93*	6	38	BEF	VT-180 Bat.†	3	32	ABCF				
VT-93 Di.	6	0	C&D	VT-181*	6	39	C&F				
VT-94*	6	42	BD	VT-182 Bat.†	3	30	ABC& AFG				
VT-94-A*	6	42	BD								
VT-94-D*	6	42	BD	VT-183 Di.	1	0	D				
VT-95	3	43	BC	VT-185 Bat.†	3	32	ABCF				
VT-96*	6	41	BC&DF	VT-188*	6	42	BC				
VT-97	5	35	C&F	VT-188 Di.	6	0	E&F				
VT-98*	6	37	BCF	VT-189*	6	41	CD&EF				
VT-99*	6	42	BE&DF	VT-190*	6	45	BCDF				
VT-101	3	44	CDEF	VT-192*	6	43	BF				
VT-103*††	6	41	FH	VT-193*	6	41	BCDF				
VT-103 Di.††	6	0	C&D	VT-194*	6	44	BCDEF				
VT-104*††	8	41	FH	VT-196*	6	43	B&D				
VT-104 Di.††	8	0	C&D	VT-197-A	5	33	C&F				

° When short checking, B&D toggles should be thrown to IN and OUT simultaneously.

§ When testing for open elements or short checking, F&G toggles should be thrown to the IN and OUT simultaneously.

** Reject point is 16 on 50 Line DC. Arc.

† Turn switch A to IN position before inserting tube; keep in this position during complete test. A lighted neon lamp will indicate continuity of third filament connection. No short test; refer to instructions.

‡ Test for cathode leakage by throwing A switch to IN when tube is hot; all other switches should be at OUT

†† Test in A socket.

¶ Place Norm. Rev. toggle in rev. position; to short check, index A toggle to IN, leaving G at IN.

|| Place Norm. Rev. toggle at Rev.

& Move grid lead to the cap that gives the higher reading.

°° Tie both caps together.

□ When testing for open elements or short testing, B&H toggles should be thrown to IN and OUT together. The same holds for C&G toggles. Check for cathode leakage.

18. COMMERCIAL TUBE TEST DATA FOR MODEL 774-4

Tube Type	Fil. Sel.	Tube Sel.	IN Pos.	Tube Type	Fil. Sel.	Tube Sel.	IN Pos.	Tube Type	Fil. Sel.	Tube Sel.	IN Pos.
1A3§ Di.	1	0	FG	3Q4 Bat.†	3	28	ABCFG	6L5-G*	6	41	BD
1A7-G Bat.	1	23	BCDEF	3Q5-GT Bat.†	3	28	ABCD	6L6*	6	43	BCD
1C5-GT Bat.	1	26	BCD	3S4 Bat.†	3	28	ABCFG	6L7*	6	43	BCDE
1C7-G Bat.	2	23	BCDEF	4A6-G Bat.†	4	24	ABC& ADF	6N6-G*	6	40	BCD
1D7 Bat.	2	18	BCDEF					6N7*	6	41	BC&DF
1D8-GT Bat.	1	22	BCD	5T4	5	42	C&F	6P5-G*	6	39	BD
1D8-GT Bat.	1	15	EF	5U4-G	5	39	C&F	6P7-G*	6	40	CDE
1D8-GT Di.	1	0	G	5V4-G	5	44	C&F	6Q6*	6	41	BE
1E5-GP Bat.	2	20	BCE	5W4	5	35	C&F	6Q6 Di.	6	0	D
1F6-G Bat.	2	19	BCE	5X4-G††	5	39	B&D	6Q7*	6	42	BE
1F6-G Di.	2	0	F&G	5Y3-G	5	33	C&F	6Q7 Di.	6	0	C&D
1F7-GV Bat.	2	19	BEF	5Y4-G††	5	33	B&D	6R6*	6	40	BDE
1F7-GV Di.	2	0	C&D	5Z3	5	39	B&C	6R7*	6	41	BE
1G5 Bat.	2	25	BCD	5Z4	5	44	C&F	6R7 Di.	6	0	C&D
1G6-G Bat.	1	23	BC&DF	6A7*	6	42	BCDEF	6S7*	6	41	BCDE
1H5-GT Bat.	1	16	BE	6A8*	6	43	BCDEF	6SA7*	6	44	BCDGH
1H5-GT Di.	1	0	D	6AB5/6N5*	6	33	BCF	6SA7-G*	6	44	BCDG
1L4 Bat.	1	25	BGF	6AB6-G*	6	37	BCD	6SC7††*	6	40	BH&CD
1LA4 Bat.	1	21	BCF	6AB7/1853*	6	44	BCFG	6SD7*	6	44	BCFG
1LA6 Bat.	1	19	BCDEF	6AC5-G*	6	42	BD	6SF5††*	6	43	BD
1LB4 Bat.	1	22	BCF	6AC6*	6	31	BCD	6SF7††*	6	41	CFH
1LC5 Bat.	1	25	BCDF	6AC7/1852*	6	45	BCFG	6SF7 Di.††	6	0	D
1LC6 Bat.	1	17	BCDEF	6AD7-G*	6	41	BCD	6SG7*	6	45	CFG
1LD5 Bat.	1	21	BCF	6AD7-G*	6	22	FH	6SH7*	6	45	CFG
1LD5 Di.	1	0	D	6AE5-GT*	6	42	BD	6SJ7*	6	42	BCFG
1LE3 Bat.	1	24	BF	6AE6-G*	6	41	BCD	6SK7*	6	42	BCFG
1LH4 Bat.	1	18	BF	6AE7-GT*	6	43	BCD	6SL7††*	6	41	CD&GH
1LH4 Di.	1	0	D	6AG5 Bat.*††	6	33	BDF	6SN7††*	6	43	CD&GH
1LN5 Bat.	1	24	BCDF	6AH7*††	6	41	BG&DF	6SQ7††*	6	41	FH
1N5-GT Bat.	1	22	BCE	6AG7*	6	43	CFGH	6SQ7 Di.††	6	0	C&D
1N6-G Bat.	1	21	BCD	6AL6*	6	44	CDE	6SR7††*	6	41	FH
1N6-G Di.	1	0	F	6B7*	6	37	BCE	6SR7 Di.††	6	0	C&D
1P5-GT Bat.	1	22	BCE	6B7 Di.	6	0	D&F	6SS7*	6	42	BCFG
1Q5-GT Bat.	1	28	BCD	6B8*	6	38	BEF	6ST7††*	6	41	FH
1R5 Bat.	1	25	BCFG	6B8 Di.	6	0	C&D	6ST7 Di.††	6	0	C&D
1S4 Bat.§	1	26	BCFG	6C4††*	6	42	BDF	6T5*	6	36	BCF
1S5 Bat.	1	18	CDF	6C5*	6	41	BD	6T7-G*	6	40	BE
1S5 Di.	1	0	B	6C6*	6	41	BCEF	6T7-G Di.	6	0	C&D
1SA6-GT Bat.	1	24	BCFG	6C7*	6	41	BE	6U5/6G5*	6	37	BCF
1SB6-GT Bat.	1	21	BCG	6C7 Di.	6	0	D&F	6U6-G*	6	44	BCD
1T4 Bat.	1	25	BFG	6C8-G*	6	41	BE&DF	6U7-G*	6	41	BCDE
1T5-GT Bat.	1	22	BCD	6D6*	6	41	BCEF	6V6*	6	42	BCD
1-V*	6	43	B	6D7*	6	42	BCDE	6V7-G*	6	37	BE
				6D8-G*	6	40	BCDEF	6V7-G Di.	6	0	C&D
2A3	3	43	BC	6E5*	6	36	BCF	6X5*	6	43	B&D
2A5*	3	41	BCF	6E6*	6	40	BC&FG	6Y5*	6	43	B&G
2A6*	3	42	BE	6E7*	6	42	BCDE	6Y6-G*	6	45	BCD
2A6 Di.	3	0	C&F	6F5*	6	43	CE	6ZY5*	6	41	B&D
2A7*	3	41	BCDEF	6F6*	6	42	BCD				
2B7*	3	35	BCE	6F8-G*	6	42	BE&DF	7A4*	6	43	BF
2B7 Di.	3	0	D&F	6G6*	6	42	BCD	7A5*	6	44	BCF
				6H4-G Di.*	6	0	C	7A6 Di.*	6	0	C&F
3A4†§ Bat.	3	30	ABCFG	6H6*	6	39	B&D	7A7*	6	43	BCDF
3A5† Bat.	3	29	ABG& ADF	6J5*	6	42	BD	7A8*	6	42	BCDEF
				6J6*††	6	44	BD&FG	7B4*	6	43	BF
3A8-GT Bat.†	3	24	ABCE	6J7*	6	41	BCDE	7B5*	6	42	BCF
3A8-GT Bat.†	3	20	ADF	6J8-G*	6	44	BCDEF	7B6*	6	42	BC
3A8-GT Di.†	3	0	AG	6K5-G*	6	42	BE	7B6 Di.	6	0	E&F
3B5-GT Bat.†	3	26	ABCD	6K6-GT*	6	42	BCD	7B7*	6	42	BCDF
3C5 Bat.†	3	27	ABCD	6K7*	6	40	BCDE	7B8*	6	42	BCDEF
3LE4 Bat.†	3	28	ABCF	6K8*	6	41	BCDEF	7C5*	6	43	BCF
3LF4† Bat.	3	32	ABCF					7C6*	6	40	BC

18. COMMERCIAL TUBE TEST DATA FOR MODEL 744-4 (Continued)

Tube Type	Fil. Sel.	Tube Sel.	IN Pos.	Tube Type	Fil. Sel.	Tube Sel.	IN Pos.	Tube Type	Fil. Sel.	Tube Sel.	IN Pos.
7C6 Di.	6	0	E&F	14Y4*	8	42	C&F	75*	6	41	BE
7C7*	6	41	BCDF	14Z3*	8	43	B	75 Di.	6	0	C&F
7E6*	6	42	BC					76*	6	39	BC
7E6 Di.	6	0	E&F	24-A*	3	40	BCE	77*	6	41	BCEF
7E7*	6	40	BEF	25A6*	9	42	BCD	78*	6	41	BCEF
7E7 Di.	6	0	C&D	25A7-G*	9	41	BCD	80	5	36	B&C
7F7*	6	41	CD&EF	25A7-G*	9	44	F	81	7	29	B
7G7 1232*	6	45	BCDF	25AC5*	9	42	BD	82	3	43	B&C
7H7*	6	45	BCDF	25L6-G*	9	45	BCD	83	5	43	B&C
7J7*	6	44	BCDEF	25Z5*	9	44	B&G	84/6Z4*	6	42	B&C
7L7*	6	44	BCDF					85*	6	37	BE
7N7*	6	43	CD&EF	26	1	36	BC	85 Di.	6	0	C&F
7Q7*	6	44	BCDEF	27*	3	39	BC	117L7-GT*	14	43	BCD
7V7*	6	45	BCDF					117L7-GT*	14	45	F
7Y4*	6	42	C&F	35A5*	10	44	BCF	117N7-GT*	14	44	BCD
7Z4*	6	39	C&F	35L6-GT*	10	44	BCD	117N7-GT†	14	45	GI
10	7	38	BC	35Y4†	10	45	AB	117P7-GT*	14	44	BCD
12A8-GT*	8	42	BCDEF	35Z3*	10	45	B	117P7-GT†	14	45	GI
12AH7*††	8	41	BG&DF	35Z4-GT*	10	45	D	117Z4-GT*	14	44	D
12F5-GT*	8	42	BE	35Z5-GT†	10	45	AD	117Z6-GT*	14	44	B&D
12H6* Di.	8	0	B&D	35Z6*	10	45	B&D	OZ4 Spec.	1	45	B&D
12J5-GT*	8	42	BD	35/51*	3	40	BCE	XXD*	8	41	CD&EF
12J7-GT*	8	42	BCDE	36*	6	40	BCE	XXL*	6	43	BF
12K7-GT*	8	41	BCDE	37*	6	39	BC				
12K8-GT*	8	44	BCDEF	38*	6	39	BCE				
12Q7-GT*	8	42	BE	39/44*	6	41	BCE				
12Q7-GT Di.	8	0	C&D	41*	6	42	BCF				
12SA7*	8	44	BCDGH	42*	6	39	BCF				
12SC7††	8	41	BH&CD	43*	9	43	BCF				
12SF5††	8	43	BD	45Z3*§	11	44	FG				
12SF7††	8	41	CFH	45Z5-GT†	11	45	AD				
12SF7 Di.††	8	0	D	45	3	41	BC				
12SG7*	8	45	CFG	50A5*	11	45	BCF				
12SH7*	8	45	CFG	50C6*	11	44	BCD				
12SJ7*	8	42	BCFG	50L6-GT*	11	45	BCD				
12SK7*	8	42	BCFG	50Y6-GT*	11	44	B&D				
12SL7*††	8	41	CD&GH	50Z6*	11	44	B&D				
12SN7*††	8	43	CD&GH	50Z7†	11	44	AB&AD				
12SQ7††	8	41	FH	50	7	37	BC				
12SQ7 Di.††	8	0	C&D	53*	3	41	BC&FG				
12SR7††	8	41	FH	55*	3	37	BE				
12SR7 Di.††	8	0	C&D	55 Di.	3	0	C&F				
14A4*	8	43	BF	56*	3	41	BC				
14A5*	8	42	BCF	57*	3	42	BCEF				
14A7*	8	42	BCDF	58*	3	42	BCEF				
14B6*	8	42	BC	59*	3	40	BCDF				
14B6 Di.	8	0	E&F	70A7-GT	12	45	BCD				
14B8*	8	42	BCDEF	70A7-GT	12	45	G				
14C5*	8	43	BCF	70L7-GT*	12	45	BCD				
14C7*	8	43	BCDF	70L7-GT*	12	44	G				
14E6*	8	42	BC								
14E6 Di.	8	0	E&F								
14F7*	8	42	CD&EF								
14H7*	8	45	BCDF								
14J7*	8	44	BCDEF								
14N7*	8	43	CD&EF								
14Q7*	8	44	BCDEF								
14S7*	8	45	BCDEF								
14W7*	8	45	BCEF								

° When short checking, B&D toggles should be thrown to the IN and OUT positions simultaneously.

§ When testing for open elements or short checking, F&G toggles should be thrown to IN and OUT simultaneously.

** Reject Point is 16 on 50 Line DC Arc.

† Turn switch A to IN before inserting tube; keep in this position during complete test. A lighted neon lamp will indicate continuity of third filament connection. No short test; refer to instructions.

* Test for cathode leakage by throwing A switch to IN when tube is hot; all other switches should be at OUT.

†† Test in A socket.

¶ Place Norm. Rev. toggle at Rev.; to short check, index A toggle to IN, leaving G at IN.

|| Place Norm. Rev. toggle at Rev.

& Move grid lead to the cap that gives the higher reading.

°° Tie both caps together.

□ When testing for open elements or short testing, B&H toggles should be thrown to IN and OUT simultaneously. The same holds for C&G toggles. Check for cathode leakage.

34

19. SUPPLEMENTARY COMMERCIAL TUBE TEST DATA (Continued)

Tube Type	Fil. Sel.	Tube Sel.	IN Pos.	Tube Type	Fil. Sel.	Tube Sel.	IN Pos.	Tube Type	Fil. Sel.	Tube Sel.	IN Pos.
71-A	5	40	BC	1201□††	6	44	BCGH	RK-19	7	44	E
79*	6	42	BC&EG	1203* Di.	6	0	D	RK-24 Bat.	2	19	BC
82V	3	43	B&C	1204†† Bat.	6	29	BCH	RK-33*	6	42	CE&DF
83V	5	43	B&C	1221*	6	40	BCEF	RK34*&	6	42	CE&EF
88M*	6	40	BCDE	1223*	6	40	BCDE				
89*	6	40	BCEF	1231*	6	46	BCDF				
				1232/7G7*	6	46	BCDF				
				1284*	8	42	BCDF				
				1291† Bat.	3	30	ABC&AFG				
				1293 Bat.	1	24	BF				
				1294 Di.	1	0	D				
				1299† Bat.	3	32	ABCF				
				1603*	6	40	BCEF				
				1610	3	40	BCG				
				1612*	6	43	BCDE				
183	5	39	BC	1619	3	42	BCDG				
231-D Bat.	3	14	BC	1620	6	42	BCDE				
239-A Bat.	1	14	BC	1621*	6	41	BCD				
244-A*	2	37	BC	1622*	6	42	BCDE				
245-A*	2	31	BCE	1624	3	42	BCE				
252-A	5	39	BC	1626*	8	41	BD				
259-A*	2	40	BCE	1629*	8	37	BCD				
262-A*	8	35	BE	1851*	6	44	BCDE				
271-A	5	36	BC	1852/6AC7*	6	45	BCFG				
274-A	5	39	B&C	1853/6AB7*	6	44	BCFG				
275-A	5	41	BC	9001*††	6	42	BDF				
283-A*	2	28	BCE	9002*°††	6	43	BDF				
305-E	6	43	BCEF	9003*††	6	42	BDF				
307-A	5	39	BCEG	9004* Di.	6	0	B				
328*	7	39	BCEF	9005 Di.	4	0	C				
350-A*	6	45	BCE								
482-A	5	39	BC								
484*	4	42	BC								
485*	4	42	BC								
585	7	38	BC								
586	7	38	BC								
713-A* Bat.	6	33	CFG								
717-A*°	6		CFG								
802*	6	41	CDEF								
837*	8	44	CDEF	HY-114-B°° Bat.	0	19	E				
841	7	38	BC	HY-615*°°	6	41	E				
842	7	40	BC	KR-1*	6	43	B				
864 Bat.	0	19	BC	KR-2*	5	44	B				
865*	7	20	BCE	KR-5	6	39	BCG				
954*	6	42	BCEF	KR-25*	3	40	BCF				
955*	6	43	BC	KR98							
956*	6	43	BCEF	01A	5	36	BC				
957** Di.	0	3	BC	0A4G Spec.	1	40	DEF				
958** Di.	0	12	BC	R-30	3	39	BC				
959** Di.	0	8	BCEF	R-100	5	30	B				
986	5	43	B&C	R-200	5	33	B				

° When short checking, B&D toggles should be thrown to the IN and OUT simultaneously.

§ When testing for open elements or short checking, F&G toggles should be thrown to IN and OUT simultaneously.

** Reject Point is 16 on 50 Line DC. Arc.

† Turn switch A to IN position before inserting tube; keep in this position during complete test. A lighted neon lamp will indicate continuity of third filament connection. No short test; refer to instructions.

* Test for cathode leakage by throwing A switch to IN position when tube is hot; all other switches should be in the OUT position.

†† Test in A socket.

¶ Place Norm. Rev. toggle in Rev. position to short check, index A toggle to IN position, leaving G in the IN position.

|| Place Norm. Rev. toggle in REV. position.

& Move grid lead to the cap that gives the higher reading.

°° Tie both caps together.

□ When testing for open elements or short testing, B&H toggles should be thrown to IN and OUT simultaneously. The same holds for C&G toggles. Check for cathode leakage.


20. CROSS INDEX OF VT AND COMMERCIAL TUBE TYPE NUMBERS

Signal Corps VT Tube Type	Commercial Tube Type	Signal Corps VT Tube Type	Commercial Tube Type	Signal Corps VT Tube Type	Commercial Tube Type
VT-25	10	VT-94	6J5	VT-172 Bat.	1S5
VT-25-A	10 Special	VT-94-A	6J5-G	VT-173 Bat.	1T4
VT-27 Bat.	30	VT-94-D	6J5-GT	VT-174 Bat.	3S4
VT-28	24A	VT-95	2A3	VT-175	1613
VT-29	27	VT-96	6N7	VT-176	1853
VT-30	01A	VT-97	5W4	VT-177 Bat.	1LH4
VT-31 Bat.	31	VT-98	6U5/6G5	VT-178 Bat.	1LC6
VT-33 Bat.	33	VT-99	6F8-G	VT-179 Bat.	1LN5
VT-35	35/51	VT-101	837	VT-180 Bat.	3LF4
VT-36	36	VT-103	6SQ7	VT-181	7Z4
VT-37	37	VT-104	12SQ7	VT-182 Bat.	1291
VT-38	38	VT-105	6SC7	VT-183 Di.	1294
VT-44 Bat.	32	VT-107	6V6	VT-185 Bat.	1299
VT-45	45	VT-107-A	6V6-GT	VT-188	7E6
VT-47	47	VT-107-B	6V6-G	VT-189	7F7
VT-48	41	VT-112	6AC7/1852	VT-190	7H7
VT-49	39/44	VT-114	5T4	VT-192	7A4
VT-50	50	VT-115	6L6	VT-193	7C7
VT-51	841	VT-115-A	6L6-G	VT-194	7J7
VT-52	45 Special	VT-116	6SJ7	VT-196	6W5-G
VT-54 Bat.	34	VT-116-B	6SJ7 Special	VT-197-A	5Y3-G
VT-55	865	VT-117	6SK7		5Y3-GT
VT-56	56	VT-120	954	VT-198-A	6G6-G
VT-57	57	VT-121	955	VT-199	6SS7
VT-58	58	VT-124 Bat.	1A5-GT	VT-201	25L6
VT-63	46	VT-125 Bat.	1C5-GT	VT-201-C	25L6-GT
VT-65	6C5	VT-126	6X5	VT-202	9002
VT-66	6F6	VT-126-A	6X5-G	VT-203	9003
VT-67 Bat.	30 Special	VT-126-B	6X5-GT	VT-205	6ST7
VT-68	6B7	VT-131	12SK7	VT-206-A	5V4-G
VT-69	6D6	VT-132	12K8	VT-207	12AH7-GT
VT-70	6F7	VT-133	12SR7	VT-208	7B8-LM
VT-72	842	VT-134	12A6	VT-209	12SG7
VT-73	843	VT-135	12J5-GT	VT-210 Bat.	1S4
VT-74	5Z4	VT-135-A	12J5	VT-211	6SG7
VT-75	75	VT-137	1625	VT-212 Di.	958
VT-76	76	VT-138	1629	VT-213-A	6L5-G
VT-77	77	VT-145	5Z3	VT-214 Di.	12H6
VT-78	78	VT-146 Bat.	1N5-GT	VT-215	6E5
VT-80	80	VT-147 Bat.	1A7-GT	VT-221 Bat.	3Q5-GT
VT-83	83	VT-148 Bat.	1D8-GT	VT-223 Bat.	1H5-GT
VT-84	84	VT-149 Bat.	3A8-GT	VT-224	RK-34
VT-86	6K7	VT-150	6SA7	VT-225	WE307-A
VT-86-A	6K7-G	VT-151	6A8-G	VT-227	KR-7184
VT-86-B	6K7-GT	VT-151-B	6A8-GT	VT-229	6SL7-GT
VT-87	6L7	VT-152	6K6-GT	VT-231	6SN7-GT
VT-87-A	6L7-G	VT-153	12C8 Special	VT-233	6SR7
VT-88	6R7	VT-161	12SA7	VT-234 Bat.	HY-114B
VT-88-A	6R7-G	VT-162	12SJ7	VT-235	HY-615
VT-89	89	VT-163	6C8-G	VT-237 Di.	957
VT-90 Di.	6H6	VT-164	1619	VT-238	956
VT-91	6J7	VT-167	6K8	VT-239 Bat.	1LE3
VT-91-A	6J7-GT	VT-168-A	6Y6-G	VT-243 Di.	1203
VT-92	6Q7	VT-169	12C8	VT-264 Bat.	3Q4
VT-92-A	6Q7-G	VT-170 Bat.	1E5-GP	VT-268	12SC7
VT-93	6B8	VT-171 Bat.	1R5		

21. COLOR CODE CHARTS FOR RESISTORS AND CAPACITORS

AMERICAN WAR STANDARD

for
CAPACITORS
(MOLDED MICA)



COLOR	1st DOT <i>1st Digit</i>	2nd DOT <i>2nd Digit</i>	3rd DOT <i>3rd Digit</i>	4th DOT <i>Decimal Multiplier</i>	5th DOT <i>Tolerance</i>	6th DOT <i>Characteristics</i>
BLACK	0	0	0	1	$\pm 20\%$	* A
BROWN	1	1	1	10		B
RED	2	2	2	100	$\pm 2\%$	C
ORANGE	3	3	3	1,000		D
YELLOW	4	4	4	10,000		E
GREEN	5	5	5	100,000		F
BLUE	6	6	6	1,000,000		G
VIOLET	7	7	7	10,000,000		
GRAY	8	8	8	100,000,000		
WHITE	9	9	9	1,000,000,000		
GOLD	—	—	—	0.1	$\pm 5\%$	
SILVER	—	—	—	0.01	$\pm 10\%$	

*

A - ORDINARY MICA BY-PASS

B - SAME AS A - LOW LOSS CASE


C - BY-PASS OR SILVER MICA CAPACITOR (± 200 PARTS / MILLION / C)D - SILVER MICA CAPACITOR (± 100 PARTS / MILLION / C)

E - SILVER MICA CAPACITOR (0 TO +100 PARTS / MILLION / C)

F - SILVER MICA CAPACITOR (0 TO +50 PARTS / MILLION / C)


G - SILVER MICA CAPACITOR (0 TO -50 PARTS / MILLION / C)

RMA. STANDARD
for
CAPACITORS
(MOLDED MICA)




COLOR	1st DOT <i>1st Digit</i>	2nd DOT <i>2nd Digit</i>	3rd DOT <i>3rd Digit</i>	4th DOT <i>Decimal Multiplier</i>	5th DOT <i>Tolerance</i>	6th DOT <i>Voltage</i>
BLACK	0	0	0	1	—	—
BROWN	1	1	1	10	1%	100 v.
RED	2	2	2	100	2%	200 v.
ORANGE	3	3	3	1,000	3%	300 v.
YELLOW	4	4	4	10,000	4%	400 v.
GREEN	5	5	5	100,000	5%	500 v.
BLUE	6	6	6	1,000,000	6%	600 v.
VIOLET	7	7	7	10,000,000	7%	700 v.
GRAY	8	8	8	100,000,000	8%	800 v.
WHITE	9	9	9	1,000,000,000	9%	900 v.
GOLD	—	—	—	0.1		1,000 v.
SILVER	—	—	—	0.01	10%	2,000 v.
BODY	—	—	—	—	20%	500 v.

RMA STANDARD
for
RESISTORS




METHOD-1



METHOD-2

COLOR	1st BAND	2nd BAND	3rd BAND	4th BAND
	<i>1st Digit</i>	<i>2nd Digit</i>	<i>Decimal Multiplier</i>	<i>Tolerance</i>
BLACK	0	0	1	
BROWN	1	1	10	
RED	2	2	100	
ORANGE	3	3	1,000	
YELLOW	4	4	10,000	
GREEN	5	5	100,000	
BLUE	6	6	1,000,000	
VIOLET	7	7	10,000,000	
GRAY	8	8	100,000,000	
WHITE	9	9	1,000,000,000	
GOLD	—	—	—	± 5%
SILVER	—	—	—	± 10%
NO COLOR	—	—	—	± 20%

COLOR CODE CHART
for
CAPACITORS
(TUBULAR CERAMIC)




COLOR	TIP <i>Temperature Coefficient</i>	1st DOT <i>1st Digit</i>	2nd DOT <i>2nd Digit</i>	3rd DOT <i>Decimal Multiplier</i>	4th DOT <i>Tolerance</i>
BLACK	0	0	0	1	—
BROWN	.00003 NEG.	1	1	10	1%
RED	.00008 "	2	2	100	2%
ORANGE	.00015 "	3	3	1,000	3%
YELLOW	.00022 "	4	4	10,000	4%
GREEN	.00033 "	5	5	100,000	5%
BLUE	.00047 "	6	6	1,000,000	6%
VIOLET	.00075 "	7	7	10,000,000	7%
GRAY		8	8	0.1	
WHITE		9	9	0.01	10%

COLOR CODE CHART

for

CAPACITORS



COLOR	1st DOT <i>1st Digit</i>	2nd DOT <i>2nd Digit</i>	3rd DOT <i>Decimal Multiplier</i>	<i>Tolerance</i>	<i>Voltage Rating</i>
BLACK	0	0	1		
BROWN	1	1	10	1%	100v.
RED	2	2	100	2%	200v.
ORANGE	3	3	1,000	3%	300v.
YELLOW	4	4	10,000	4%	400v.
GREEN	5	5	100,000	5%	500v.
BLUE	6	6	1,000,000	6%	600v.
VIOLET	7	7	10,000,000	7%	700v.
GRAY	8	8	100,000,000	8%	800v.
WHITE	9	9	1,000,000,000	9%	900v.
GOLD	—	—	0.1		1000v.
SILVER	—	—	0.01	10%	2000v.
BODY	—	—	—	20%	*

* WHEN NO COLOR IS INDICATED THE VOLTAGE RATING MAY BE AS LOW AS 300 VOLTS.

22. TABLE OF REPLACEABLE PARTS

*Note: No reference number given, as diagrams show directly essential identification information.

Sig. Corps Stock No.	Name of Part	Description	Function	Name or Sym. of Mfr.	Drawing No.
	Carrying Case	#19 gauge steel 19 $\frac{1}{4}$ " x 13 $\frac{5}{8}$ " x 6 $\frac{3}{8}$ ", with Sig. Corps nameplate per mfr's. drawing, D-79683	For carrying pocket meters, large analyzers, all leads, and instructions	W	D-106275
MODEL 564 TYPE 3C VOLT-OHMMETER COMPLETE					
	Case	Moulded bakelite 5 $\frac{1}{2}$ " x 3 $\frac{5}{8}$ " x 1 $\frac{7}{8}$ ", with Sig. Corps nameplate per mfr's. drawing, D-76981	For enclosing volt-ohmmeter	W	D-66311
	Cover	Moulded bakelite panel with glass, zero corrector, pin jack, rheostat, and switch mounting holes.	For carrying meter, etc.	W	D-106256
	Pin Jack	Standard phone tip jack $\frac{1}{4}$ -32 thread to fit moulded panel.	To make test lead connections	Y	D-72923
	Switch	Single Pole Double Throw Toggle switch $\frac{1}{4}$ " shank	To shift from volts to ohms	F	ND-20178
	Rheostat	10,000 Ω Approx. $\frac{3}{4}$ " dia. Type PSM.	For battery adjustment	S	ND-22935
	Knob	Moulded bakelite, small diameter	For battery adjustment rheostat	W	ND-22899
	Clamp	Formed spring type to fit flat 3-cell 4.5-volt battery	For holding the ohmmeter battery	W	D-72901
	Terminal Plate	$\frac{1}{16}$ " punched sheet bakelite 1 $\frac{5}{8}$ " x 2 $\frac{3}{4}$ "	For mounting spools and other wire wound resistors	W	D-106258
	Resistor	1.2 Meg. Ceramic tube type	1800-volt range	I	D-106257
	Resistor	300,000-ohm spool Type RL	600-volt range	I	D-68068
	Resistor	270,000-ohm spool Type RL	300-volt range	I	D-65221
	Resistor	34,350-ohm spool Type RL	R x 1000 series	I	D-81250
	Resistor	29,880-ohm spool Type RL	R x 1000 shunt	I	D-81251
	Resistor	2,988-ohm spool Type RL	R x 100 shunt	I	D-81252
	Resistor	500-ohm spool Type WL	R x 100 series	I	D-81253
	Resistor	299-ohm spool Type WL	R x 10 shunt	I	D-81254
	Resistor	27,000-ohm spool Type RL	30-volt range	I	D-81257
	Resistor	29,240-ohm spool Type RL	3-volt series	I	D-81258
	Resistor	3,333-ohm spool Type RL	Voltmeter shunt	I	D-81259
	Resistor	33.2-ohm spool Type WL	R range shunt	I	D-79574
	Resistor	19-ohm spool Type WL	R x 10 series	I	D-79575
	Resistor	2,000-ohm $\frac{1}{4}$ w. carbon	Batt. adj. limiter	N	ND-21091
	Lead	Black rubber covered with terminal	Battery connection	W	D-73058
	Lead	Red rubber covered with terminal	Battery connection	W	D-73059

22. TABLE OF REPLACEABLE PARTS (Continued)

Sig. Corps Stock No.	Name of Part	Description	Function	Name or Sym. of Mfr.	Drawing No.
MODEL 571 TYPE 3A OUTPUT METER					
Meter	Model 301 mtd. on base		Indicator	W	Spec. 636-19
Case	Moulded bakelite 5½" x 3⅝" x 1⅞", with Sig. Corps nameplate per Mfr's. drawing, D-79682.		For enclosing output meter	W	D-66311
Cover	Moulded bakelite panel with glass and zero corrector, pin jack and rotary switch mounting holes		For carrying meter switch & pin jacks	W	D-73021
Pin Jack	Standard phone tip jack ¼-32 thread to fit moulded panel		To make test lead connections	Y	D-72923
Switch	Moulded bakelite, 5-pole single deck		Range selection	W	D-81221
Dial	Moulded bakelite with a flat skirt for markings		Switch indexing	W	D-73702
Resistor	3000-ohm resistor, type BCN		6-volt series	N	D-66198
Resistor	300-ohm spool type RL		60-volt series	N	D-72942
Resistor	600-ohm spool type SL		15-volt series	N	D-66196
Resistor	888.9-ohm spool type RL		6-volt shunt	N	D-66194
Resistor	40.4-ohm spool type RL		150-volt shunt	N	D-72914
Resistor	60-ohm resistor type ALN		150-volt series	N	D-72928
Resistor	62.1-ohm spool type RL		60-volt shunt	N	D-72905
Resistor	341.9-ohm spool type RL		15-volt shunt	N	D-73868
Capacitor	.1 mfd., 300 volt moulded, two in parallel. Micamold Type 345		D.C. blocking	M	ND-21763
Meter	Model 301 mounted on base		Indicator	W	Spec. 645-19
MODEL 774 TYPE 4 COMBINATION ANALYZER-TUBE CHECKER					
Case	Wood 11¼" x 14" x 5⅞" with detachable cover and compartment for socket selector and adapters		Carrying the combination and necessary adapters	W	D-106274
Panel	Screened steel with holes for sockets, meter, controls, and socket selector		Carries meter, controls, etc.	W	D-106277
Socket	4-,5-,6-prong combination, per mfr's. drawing		Tube testing	A	D-106299
Socket	7-prong, combination large and small per mfr's. drawing		Tube testing	A	D-106298
Socket	7-prong miniature per mfr's. drawing		Tube testing	A	D-93590
Socket	8-prong loctal per mfr's. drawing		Tube testing	A	D-93473
Socket	8-prong octal per mfr's. drawing		Tube testing	A	D-106297

22. TABLE OF REPLACEABLE PARTS (Continued)

Sig. Corps Stock No.	Name of Part	Description	Function	Name or Sym. of Mfr.	Drawing No.
MODEL 774 TYPE 4 COMBINATION ANALYZER-TUBE CHECKER—Continued					
Socket	8-prong octal per mfr's. drawing	Tube testing	A	D-108923	
Socket	Acorn per mfr's. drawing	Tube testing	A	D-91281	
Neon Lamp	G. E. ¼-watt, candelabra base	Short testing	G	ND-20284	
Socket	Candelabra with mounting bracket per mfr's. drawing	For neon lamp	D	D-85229	
Pin Jacks	Eby bakelite, # 52K with locking clamp	To make test lead connections	E	ND-22752	
Rheostat	350-ohm vitreous type, 25-watt, with shaft drilled per mfr's. drawing	Line voltage control	H	D-85230	
Rotary Switch	4-deck assembled per mfr's. drawing	Range selection	Y	D-106273	
Rotary Switch	2-deck assembled per mfr's. drawing	Filament voltage selection	Y	D-106288	
Rotary Switch	6-deck assembled per mfr's. drawing	Circuit selector	Y	D-106272	
Potenti- ometer	2-deck 150 & 15,000 ohms per mfr's. drawing	Tube selector and ohmmeter adjuster	B	D-106265	
Bar knobs	Black moulded bakelite	For switches and potentiometer	W	D-83038	
Set screws	# 729, pin type	For bar knobs	W	D-76857	
Switches	S.P.D.T. Toggle, red bakelite lever, ¼" shank	Tube testing	F	ND-22731	
Switch	D.P.D.T. toggle ¼" shank	Meter reversing	F	ND-22713	
Bracket	Steel, ½" strip stock, 6⅜" long, with tube socket bracket	For mounting transformer	W	D-106281	
Bracket	Steel ½" strip stock, 5¼" long	For mounting transformer (bottom)	W	D-106282	
Socket	4-prong Wafer, 1⅞" between mount- ing holes.	For mounting 71-A tube	C	J-11617	
Tube	Commercial 71-A	Short test and line voltage reading	R	ND-20775	
Trans- former	Assembled with terminal plate & filament leads	Supplies all necessary potentials	W	D-106278	
Resistor	500,000-ohm ½-watt carbon	Neon lamp shunt	N	ND-20259	
Resistor	200,000 ohm ½-watt carbon	Neon lamp series	N	ND-22772	
Resistor Mtg. Plates	Sheet bakelite with terminals, 4" x 1¾"	For mtg. resistors	W	D-106276	

22. TABLE OF REPLACEABLE PARTS (Continued)

Sig. Corps Stock No.	Name of Part	Description	Function	Name or Sym. of Mfr.	Drawing No.
MODEL 774 TYPE 4 COMBINATION ANALYZER-TUBE CHECKER—Continued					
Resistor	2000-ohm brown devil 2-watt		Tube load, special types	0	ND-22116
Resistor	Plate #1 assembled, includes the following matched pair resistors. This is the resistor plate nearest the panel. Refer to assembly drawing for location of each pair.		Assembly		D-106291
Resistor	37,500-ohm carbon Type BT ½		Rx1000 range series	N	ND-22804
Resistor	3,750-ohm carbon Type BT ½		Rx100 range series	N	ND-22805
Resistor	26,224-ohm carbon Type BT ½		Rectifier series for capacity	N	ND-22806
Resistor	70,300-ohm carbon Type BT ½		C+100 range series	N	ND-22807
Resistor	.280-ohm carbon Type BW ½		500 MA range shunt	N	ND-22808
Resistor	1.10-ohm carbon Type BW ½		100 MA range shunt	N	ND-22809
Resistor	12.38-ohm carbon Type BW ½		10 MA range shunt	N	ND-22810
Resistor	123.8-ohm carbon Type BW ½		1 MA range shunt	N	ND-22811
Resistor	2087-ohm carbon Type BT ½		Meter series, for D.C. Volts 1M ohms/V	N	ND-22812
Resistor	Plate #2 assembled, includes the following matched pair resistors. This is the second resistor plate from the panel. Refer to assembly drawing for location of each pair.		Assembly		D-106290
Resistor	76-ohm carbon Type BW ½		Cx10 range shunt	N	ND-22794
Resistor	726-ohm carbon Type BW ½		C range shunt	N	ND-22795
Resistor	9,500-ohm carbon Type BW ½		C+10 range shunt	N	ND-22796
Resistor	686-ohm carbon Type BW ½		Rx100 range shunt	N	ND-22797
Resistor	471.6-ohm carbon Type BW ½		Rx10 range shunt	N	ND-22798
Resistor	49.4-ohm carbon Type BW ½		R Direct range shunt	N	ND-22799
Resistor	11,500-ohm carbon Type BT ½		Meter series for ohms	N	ND-22800
Resistor	4,000-ohm carbon Type BT ½ (Single, not paired)		Battery adjuster series	N	ND-22801
Resistor	5 meg. carbon Type BT ½		1000 V series, 10M ohms/V	N	ND-22802
Resistor	3.5 meg. carbon Type BT ½		500 V series, 10M ohms/V	N	ND-22803
Resistor	Plate #3 assembled, includes the following matched pair resistors. This is the third resistor plate from the panel. Refer to assembly drawing for location of each pair.		Assembly		D-106289
Resistor	.5 meg. carbon Type BT ½		1000 V. series 1M ohms/V	N	ND-22785

22. TABLE OF REPLACEABLE PARTS (Continued)

Sig. Corps Stock No.	Name of Part	Description	Function	Name or Sym. of Mfr.	Drawing No.	
MODEL 774 TYPE 4 COMBINATION ANALYZER-TUBE CHECKER—Continued						
Resistor	.35 meg. carbon Type BT ½		500 V. series 1M ohms/V and 1000 V series 10M ohms/V	N	ND-22792	
Resistor	.1 meg. carbon Type BT ½		150 V. series 1M ohms/V	N	ND-22786	
Resistor	35,000-ohm carbon Type BT ½		50 V. series 1M ohms/V	N	ND-22787	
Resistor	7,500-ohm carbon Type BT ½		15 V. series 1M ohms/V	N	ND-22788	
Resistor	5,289-ohm carbon Type BT ½		7.5 V. series 1M ohms/V	N	ND-22789	
Resistor	73,800-ohm carbon Type BT ½		7.5 V. series 10M ohms/V	N	ND-22790	
Resistor	75,000-ohm carbon Type BT ½		15 V. series, 10M ohms/V	N	ND-22791	
Resistor	1 megohm carbon Type BT ½		150 V. series, 10M ohms/V	N	ND-22793	
Resistor Plate #4 assembled, includes the follow- ing matched pair resistors. This is the fourth resistor plate from the panel. Refer to manu- facturer's assembly drawing for location of each pair.			Assembly		D-106292	
Resistor	3,664-ohm carbon Type BT ½		Rectifier bridge circuit	N	ND-22813	
Resistor	377-ohm carbon Type BW ½		Shunt for A-C volts	N	ND-22814	
Resistor	88.36-ohm carbon Type BW ½		Meter shunt for tube testing	N	ND-22815	
Resistor	300-ohm carbon Type BW ½		Tube testing	N	ND-22816	
Resistor	135,500-ohm carbon Type BT ½		Line check series	N	ND-22817	
Resistor	3,935-ohm carbon Type BT ½		Tube testing-diodes	N	ND-22818	
Resistor	765-ohm carbon Type BW ½		Tube testing-battery types	N	ND-22819	
Resistor	3,000-ohm carbon	} Type TB	Selected for line check	N	ND-21656	
	6,000-ohm carbon		½		adjustment, only 1	ND-22733
	9,000-ohm carbon		Not		required	ND-22734
	12,000-ohm carbon		Paired			ND-22735
Resistor	40-ohm wire wound Type BW ½		Tube testing	N	ND-22750	
Resistor	3-ohm wire-wound Type BW ½		Tube testing	N	ND-22749	
Resistor	165-ohm wire-wound Type BW ½		Tube testing	N	ND-22751	
Capacitor	.5 mfd. Solar Type MP 200-Volts D-C		Filter for short checking & line check potential	J	ND-21079	
Rectifier	Weston bridge type with brown dot		Instrument rectifier for A-C ranges	W	D-89353	

22. TABLE OF REPLACEABLE PARTS (Continued)


Sig. Corps Stock No.	Name of Part	Description	Function	Name or Sym. of Mfr.	Drawing No.
MODEL 774 TYPE 4 COMBINATION ANALYZER-TUBE CHECKER—Continued					
Battery clamp	Weston type with snap ring		To hold 1.5-volt battery	W	D-106168
Battery clamp	Formed spring type to fit flat 3-cell 4.5-volt battery		To hold 4.5-volt battery	W	D-108907
Lead	Rubber covered with pin clip		Tube top cap connector Plate lead for Acorn tubes	W	D-91290
Lead	Rubber covered with double cap connector		Tube top cap connector, other types	W	D-106295
Line Cord	Complete with bakelite fused plug —Two 1 amp. fuses in plug		For A-C line connection	W	D-76868
Meter	Model 801 complete		Indicator—all functions	W	Spec. M176-4
Socket Selector	Model 666 Type 1-C-1		Analyzer Testing	W	D-106279
Capacitor	.25 mfd. Solar Tubular Type 600 volts D-C		Series cap to pin jack for output meter readings	J	ND-21578
The following socket and plug adapters are mounted in the wood block located in the Model 774 carrying case compartment:					
Adapter	4-prong skirted (red)		For 4-prong tubes	W	D-70194
Adapter	5-prong skirted (green)		For 5-prong tubes	W	D-70195
Adapter	6-prong skirted (blue)		For 6-prong tubes	W	D-70196
Adapter	7-prong skirted (black)		For large 7-prong tubes	W	D-70187
Adapter	Octal skirted (orange)		For octal tubes	W	D-70131
Adapter	Loctal skirted (brown)		For loctal tubes	W	D-70139
Adapter	Miniature skirted (black)		For miniature tubes	W	D-70144
Adapter	4-prong plug (red)		For 4-prong tubes	W	D-70120
Adapter	5-prong plug (green)		For 5-prong tubes	W	D-70123
Adapter	6-prong plug (blue)		For 6-prong tubes	W	D-70124
Adapter	Small 7-prong plug (brown)		Small 7-prong tubes	W	D-70126
Adapter	Large 7-prong plug (black)		Large 7-prong tubes	W	D-70127
Adapter	8-prong octal plug (orange)		For octal tubes	W	D-70130
Adapter	Loctal plug (brown)		For loctal tubes	W	D-70132
Adapter	Miniature plug		For miniature tubes	W	D-70143

PUBLICATION		TEST SET: MDL: I-56-E. MAINTENANCE MANUAL DTD 23 JULY 1943		CHARGE OUT RECORD CARD	
DATE ISSUED	SIGNATURE OF RECIPIENT	DIVISION SECTION OR OFFICE		DATE RETURNED	

PUBLICATION	CHARGE OUT RECORD CARD
-------------	------------------------

DATE ISSUED	SIGNATURE OF RECIPIENT	DIVISION SECTION OR OFFICE	DATE RETURNED







TM 11-321-1